

Contents

Overview	1
Front panel	2
LEDs	2
Technical specifications	4
Power module configuration	4
Installing and removing the power module	6
Installing the power module.....	6
Installing the power module	7
Connecting the power cord	9
Removing the power module	10
Removing the power cord.....	10
Removing the power module.....	11

Overview

The PSR2400-54D DC-input and DC-output power module is hot swappable and provides a maximum output of 2400 W.


Table 1 PSR2400-54D power module features

Feature	Description
Protection	Protection against input under-voltage, input over-voltage, output over-voltage, output short circuit, output under-current, output over-current, and overheat.
Redundancy	The power modules can operate in N+1 or N+N redundancy. For more information, see " Power module configuration ."
Hot swapping	You can install or remove a power module when the device is operating.

The power module shuts down automatically when its temperature exceeds the acceptable range. When the temperature returns to the acceptable range, the power module automatically restarts.

Front panel

Figure 1 Front panel



(1) Power input LED

(2) Handle

(3) Screw hole for fastening the power cord connector

(4) Latch

(5) DC-input receptacle

(6) Power output LED

(7) Air vents

LEDs

The PSR2400-54D power module has two LEDs.

Table 2 LED description

LED	Mark	Color	Description
Power input LED	INPUT OK	Off	No DC power input.
			Low DC input voltage. The power module has entered protected state.
		Green	Normal DC input.
Power output LED	OUTPUT OK	Green	Normal DC output.
		Red	DC output failure. An alarm condition occurs, for example, output short circuit, output over-current, output over-voltage, output under-voltage, or remote shutdown. The power module has entered the protected state.
		Orange	High temperature.

NOTE:

After the circuit breaker of the power module is switched off, the LEDs on the power module will remain on for a while.

Technical specifications

Table 3 Technical specifications

Item		Specifications
Rated input voltage		-48 V to -60 V
Rated output voltage		54 V
Maximum input current		80 A
Maximum output current		44.5 A
Maximum output power		2400 W
Dimensions (H x W x D)		41 x 100 x 332 mm (1.61 x 3.94 x 13.07 in)
Ambient temperature	Operating temperature	-10°C to +50°C (-14°F to +122°F)
	Storage temperature	-40°C to +70°C (-40°F to +158°F)

Power module configuration

Follow these guidelines to configure power modules for the device:

- Determine the total number of power modules based on the actual power consumption, the power module slot number, and power redundancy design.
- Determine the power module redundancy design based on the power source conditions.
 - When two mains power inputs are provided, you can configure the power modules in N+N redundancy. N+N must be not greater than the total number of power module slots.


- When one mains power input is provided, you can configure the power modules in N+1 or N+N redundancy. N+1 or N+N must be not greater than the total number of power module slots.
- For easy usage and maintenance, configure a circuit breaker for each power input. The rated current of the circuit breaker must be a minimum of 120 A.

Installing and removing the power module

Installing the power module

To avoid bodily injury and device damage, follow the procedures in [Figure 2](#) to install a power module.

Figure 2 Power module installation procedure



Before the installation, prepare an ESD wrist strap and a flat-blade screwdriver yourself.

Installing the power module

1. Wear an ESD wrist strap, and make sure the strap makes good skin contact and is reliably grounded.
2. Remove the blank panel from the target power module slot.
 - If the blank panel is as shown in [Figure 3](#), thread the flat-blade screwdriver through the hole in the handle of the blank panel and pull the blank panel out.
 - If the blank panel is as shown in [Figure 4](#), put your forefinger in the hole in the blank panel and pull the blank panel out.

Skip this step if the target slot does not have any blank panel installed.

Figure 3 Removing a blank panel (1)





Figure 4 Removing a blank panel (2)




- 3.** Unpack the power module.
- 4.** Correctly orient the power module.

If you install the power module in a left power module slot, make sure the latch is above the handle. If you install the power module in a right power module slot, make sure the latch is below the handle.

- 5.** Holding the handle of the power module with one hand and supporting the bottom of the power module with the other, slide the power module along the guide rails into the slot until you hear a click.

The power module is foolproof. If the power module is oriented incorrectly, you cannot install the power module into the slot. If you encounter a hard resistance while inserting the power module, pull out the power module, reorient it, and then insert it again.

Figure 5 Installing the power module



Connecting the power cord



WARNING!

- Make sure each power cord has a separate circuit breaker.
- Before you connect the DC power cord to the DC source terminal block. Make sure the circuit breakers are turned off.


To connect the power cord:

1. Insert the power cord connector into the DC input receptacle on the power module.
2. Fasten the screw to secure the connector in place.
3. Connect the two wires at the other end of the DC power cord to the DC source terminal block.

Removing the power module

To avoid device damage and bodily injury, follow the procedures in [Figure 6](#) to remove the power module.

Figure 6 Power module removal procedure



Before you remove the power module, prepare an ESD wrist strap yourself.

Removing the power cord

1. Turn off the circuit breaker of the power cord.
2. Wear an ESD wrist strap, and make sure the strap makes good skin contact and is reliably grounded.
3. Loosen the screw that secures the power cord connector to the power module, and pull the power cord out.

Removing the power module


CAUTION:

- Before you insert a removed power module into a power module slot, make sure the LEDs on the power module are off.
- Avoid scalding your hands when you remove the power module.

To remove the power module:

1. Pressing the latch towards the handle direction, pull the power module out along the guide rails until it is part way out of the slot.
2. As shown in [Figure 7](#), grasping the handle of the power module with one hand and supporting the bottom of the power module with the other hand, pull the module slowly along the guide rails out of the slot.

Figure 7 Removing the power module



3. Place the power module on an antistatic mat.
4. Install the blank panel in the power module slot.