

Contents

IP performance optimization commands.....	1
display icmp statistics.....	1
display ip statistics.....	1
display rawip	3
display rawip verbose.....	4
display tcp	6
display tcp statistics	7
display tcp verbose.....	9
display udp	13
display udp statistics	14
display udp verbose.....	14
ip forward-broadcast	17
ip icmp error-interval	18
ip icmp source	19
ip mtu	19
ip reassemble local enable	20
ip redirects enable	21
ip ttl-expires enable.....	21
ip unreachable enable.....	22
reset ip statistics	23
reset tcp statistics.....	23
reset udp statistics.....	24
tcp mss	24
tcp path-mtu-discovery	25
tcp syn-cookie enable.....	26
tcp timer fin-timeout	26
tcp timer syn-timeout.....	27
tcp window.....	28

IP performance optimization commands

display icmp statistics

Use `display icmp statistics` to display ICMP statistics.

Syntax

```
display icmp statistics [ slot slot-number ]
```

Views

Any view

Predefined user roles

network-admin

network-operator

Parameters

`slot slot-number`: Specifies an IRF member device by its member ID. If you do not specify a member device, this command displays ICMP statistics for all member devices.

Usage guidelines

ICMP statistics include information about received and sent ICMP packets.

Examples

Display ICMP statistics.

```
<Sysname> display icmp statistics
```

```
Input: bad formats      0                bad checksum          0
       echo             175            destination unreachable 0
       source quench    0                redirects             0
       echo replies     201            parameter problem     0
       timestamp        0                information requests  0
       mask requests    0                mask replies         0
       time exceeded    0                invalid type          0
       router advert    0                router solicit        0
       broadcast/multicast echo requests ignored 0
       broadcast/multicast timestamp requests ignored 0
Output: echo            0                destination unreachable 0
       source quench    0                redirects             0
       echo replies     175            parameter problem     0
       timestamp        0                information replies   0
       mask requests    0                mask replies         0
       time exceeded    0                bad address           0
       packet error     1442            router advert         3
```

display ip statistics

Use `display ip statistics` to display IP packet statistics.

Syntax

```
display ip statistics [ slot slot-number ]
```

Views

Any view

Predefined user roles

network-admin

network-operator

Parameters

slot slot-number: Specifies an IRF member device by its member ID. If you do not specify a member device, this command displays IP packet statistics for all member devices.

Usage guidelines

IP statistics include information about received and sent packets, fragments, and reassembly.

Examples

Display IP packet statistics.

```
<Sysname> display ip statistics
  Input:  sum          7120          local          112
         bad protocol  0           bad format     0
         bad checksum  0           bad options    0
  Output: forwarding   0           local          27
         dropped       0           no route       2
         compress fails 0
  Fragment:input      0           output         0
         dropped       0
         fragmented    0           couldn't fragment 0
  Reassembling:sum    0           timeouts       0
```

Table 1 Command output

Field	Description
Input	Statistics about received packets: <ul style="list-style-type: none">• sum—Total number of packets received.• local—Total number of packets destined for the device.• bad protocol—Total number of unknown protocol packets.• bad format—Total number of packets with incorrect format.• bad checksum—Total number of packets with incorrect checksum.• bad options—Total number of packets with incorrect option.
Output	Statistics about sent packets: <ul style="list-style-type: none">• forwarding—Total number of packets forwarded.• local—Total number of packets locally sent.• dropped—Total number of packets discarded.• no route—Total number of packets for which no route is available.• compress fails—Total number of packets failed to be compressed.

Field	Description
Fragment	Statistics about fragments: <ul style="list-style-type: none"> • input—Total number of fragments received. • output—Total number of fragments sent. • dropped—Total number of fragments dropped. • fragmented—Total number of packets successfully fragmented. • couldn't fragment—Total number of packets failed to be fragmented.
Reassembling	Statistics about reassembly: <ul style="list-style-type: none"> • sum—Total number of packets reassembled. • timeouts—Total number of reassembly timeouts.

Related commands

```
display ip interface
reset ip statistics
```

display rawip

Use `display rawip` to display brief information about RawIP connections.

Syntax

```
display rawip [ slot slot-number ]
```

Views

Any view

Predefined user roles

```
network-admin
network-operator
```

Parameters

`slot slot-number`: Specifies an IRF member device by its member ID. If you do not specify a member device, this command displays brief information about RawIP connections for all member devices.

Usage guidelines

Brief RawIP connection information includes local and peer addresses, protocol, and PCB.

Examples

```
# Display brief information about RawIP connections.
```

```
<Sysname> display rawip
```

```
Local Addr      Foreign Addr    Protocol  Slot   PCB
0.0.0.0         0.0.0.0        1         1     0x0000000000000009
0.0.0.0         0.0.0.0        1         1     0x0000000000000008
```

Table 2 Command output

Field	Description
Local Addr	Local IP address.
Foreign Addr	Peer IP address.
Protocol	Protocol number.

Field	Description
PCB	Protocol control block.

display rawip verbose

Use `display rawip verbose` to display detailed information about RawIP connections.

Syntax

```
display rawip verbose [ slot slot-number [ pcb pcb-index ] ]
```

Views

Any view

Predefined user roles

network-admin

network-operator

Parameters

pcb *pcb-index*: Displays detailed RawIP connection information for the specified PCB. The *pcb-index* argument specifies the index of the PCB. The index is a hexadecimal string in the range of 1 to ffffffff.

slot *slot-number*: Specifies an IRF member device by its member ID. If you do not specify a member device, this command displays detailed information about RawIP connections for all member devices.

Usage guidelines

The detailed information includes socket creator, state, option, type, protocol number, and the source and destination IP addresses of RawIP connections.

Examples

Display detailed information about RawIP connections.

```
<Sysname> display rawip verbose
```

```
Total RawIP socket number: 1
```

```
Location: slot: 6 cpu: 0
```

```
Creator: ping[320]
```

```
State: N/A
```

```
Options: N/A
```

```
Error: 0
```

```
Receiving buffer(cc/hiwat/lowat/drop/state): 0 / 9216 / 1 / 0 / N/A
```

```
Sending buffer(cc/hiwat/lowat/state): 0 / 9216 / 512 / N/A
```

```
Type: 3
```

```
Protocol: 1
```

```
Connection info: src = 0.0.0.0, dst = 0.0.0.0
```

```
Inpcb flags: N/A
```

```
Inpcb extflag: INP_EXTRCVICMPERR INP_EXTFILTER
```

```
Inpcb vflag: INP_IPV4
```

```
TTL: 255(minimum TTL: 0)
```

```
Send VRF: 0xffff
```

```
Receive VRF: 0xffff
```

Table 3 Command output

Field	Description
Total RawIP socket number	Total number of RawIP sockets.
Creator	Name of the operation that created the socket. The number in brackets is the process number of the creator.
State	State of the socket.
Options	Socket options.
Error	Error code.
Receiving buffer (cc/hiwat/lowat/drop/state)	<p>Displays receive buffer information in the following order:</p> <ul style="list-style-type: none"> • cc—Used space. • hiwat—Maximum space. • lowat—Minimum space. • drop—Number of dropped packets. • state—Buffer state: <ul style="list-style-type: none"> ○ CANTSENDMORE—Unable to send data to the peer. ○ CANTRCVMORE—Unable to receive data from the peer. ○ RCVATMARK—Receiving tag. ○ N/A—None of the above states.
Sending buffer (cc/hiwat/lowat/state)	<p>Displays send buffer information in the following order:</p> <ul style="list-style-type: none"> • cc—Used space. • hiwat—Maximum space. • lowat—Minimum space. • state—Buffer state: <ul style="list-style-type: none"> ○ CANTSENDMORE—Unable to send data to the peer. ○ CANTRCVMORE—Unable to receive data from the peer. ○ RCVATMARK—Receiving tag. ○ N/A—None of the above states.
Type	<p>Socket type:</p> <ul style="list-style-type: none"> • 1—SOCK_STREAM. This socket uses TCP to provide reliable transmission of byte streams. • 2—SOCK_DGRAM. This socket uses UDP to provide datagram transmission. • 3—SOCK_RAW. This socket allows an application to change the next upper-layer protocol header. • N/A—None of the above types.
Protocol	Number of the protocol using the socket.
Connection info	Source IP address and destination IP address.

Field	Description
Inpcb flags	<p>Flags in the Internet PCB:</p> <ul style="list-style-type: none"> • INP_RECVOPTS—Receives IP options. • INP_RECVRETOPTS—Receives replied IP options. • INP_RECVSTADDR—Receives destination IP address. • INP_HDRINCL—Provides the entire IP header. • INP_REUSEADDR—Reuses the IP address. • INP_REUSEPORT—Reuses the port number. • INP_ANONPORT—Port number not specified. • INP_RECVIF—Records the input interface of the packet. • INP_RECVTTL—Receives TTL of the packet. Only UDP and RawIP support this flag. • INP_DONTFRAG—Sets the Don't Fragment flag. • INP_ROUTER_ALERT—Receives packets with the router alert option. Only RawIP supports this flag. • INP_PROTOCOL_PACKET—Identifies a protocol packet. • INP_RCVLANID—Receives the VLAN ID of the packet. Only UDP and RawIP support this flag. • INP_RCVMACADDR—Receives the MAC address of the frame. • INP_RECVTOS—Receives TOS of the packet. Only UDP and RawIP support this flag. • INP_USEICMPSRC—Uses the specified IP address as the source IP address for outgoing ICMP packets. • INP_SYNCPCB—Waits until Internet PCB is synchronized. • N/A—None of the above flags.
Inpcb extflag	<p>Extension flags in the Internet PCB:</p> <ul style="list-style-type: none"> • INP_EXTRCVPVCIDX—Records the PVC index of the received packet. • INP_RCVPWID—Records the PW ID of the received packet. • INP_EXTRCVICMPERR—Receives an ICMP error packet. • INP_EXTFILTER—Filters the contents in the received packet. • N/A—None of the above flags.
Inpcb vflag	<p>IP version flags in the Internet PCB:</p> <ul style="list-style-type: none"> • INP_IPV4—IPv4 protocol. • INP_TIMEWAIT—In TIMEWAIT state. • INP_ONESBCAST—Sends broadcast packets. • INP_DROPPED—Protocol dropped flag. • INP_SOCKREF—Strong socket reference. • INP_DONTBLOCK—Do not block synchronization of the Internet PCB. • N/A—None of the above flags.
TTL	TTL value in the Internet PCB.
Send VRF	VRF from which packets are sent.
Receive VRF	VRF from which packets are received.

display tcp

Use `display tcp` to display brief information about TCP connections.

Syntax

```
display tcp [ slot slot-number ]
```

Views

Any view

Predefined user roles

network-admin
network-operator

Parameters

slot slot-number: Specifies an IRF member device by its member ID. If you do not specify a member device, this command displays brief information about TCP connections for all member devices.

Usage guidelines

Brief TCP connection information includes local IP address, local port number, peer IP address, peer port number, and TCP connection state.

Examples

Display brief information about TCP connections.

```
<Sysname> display tcp
*: TCP connection with authentication
Local Addr:port      Foreign Addr:port    State      Slot  PCB
*0.0.0.0:21          0.0.0.0:0            LISTEN     1     0x0000000000000c387
192.168.20.200:23    192.168.20.14:1284   ESTABLISHED 1     0x0000000000000009
192.168.20.200:23    192.168.20.14:1283   ESTABLISHED 1     0x0000000000000002
```

Table 4 Command output

Field	Description
*	Indicates that the TCP connection uses authentication.
Local Addr:port	Local IP address and port number.
Foreign Addr:port	Peer IP address and port number.
State	TCP connection state.
PCB	PCB index.

display tcp statistics

Use **display tcp statistics** to display TCP traffic statistics.

Syntax

```
display tcp statistics [ slot slot-number ]
```

Views

Any view

Predefined user roles

network-admin
network-operator

Parameters

slot *slot-number*: Specifies an IRF member device by its member ID. If you do not specify a member device, this command displays TCP traffic statistics for all member devices.

Usage guidelines

TCP traffic statistics include information about received and sent TCP packets and Syncache/syncookie.

Examples

Display TCP traffic statistics.

```
<Sysname> display tcp statistics
```

```
Received packets:
```

```
Total: 4150
packets in sequence: 1366 (134675 bytes)
window probe packets: 0, window update packets: 0
checksum error: 0, offset error: 0, short error: 0
packets dropped for lack of memory: 0
packets dropped due to PAWS: 0
duplicate packets: 12 (36 bytes), partially duplicate packets: 0 (0 bytes)
out-of-order packets: 0 (0 bytes)
packets with data after window: 0 (0 bytes)
packets after close: 0
ACK packets: 3531 (795048 bytes)
duplicate ACK packets: 33, ACK packets for unsend data: 0
```

```
Sent packets:
```

```
Total: 4058
urgent packets: 0
control packets: 50
window probe packets: 3, window update packets: 11
data packets: 3862 (795012 bytes), data packets retransmitted: 0 (0 bytes)
ACK-only packets: 150 (52 delayed)
unnecessary packet retransmissions: 0
```

```
Syncache/syncookie related statistics:
```

```
entries added to syncache: 12
syncache entries retransmitted: 0
duplicate SYN packets: 0
reply failures: 0
successfully build new socket: 12
bucket overflows: 0
zone failures: 0
syncache entries removed due to RST: 0
syncache entries removed due to timed out: 0
ACK checked by syncache or syncookie failures: 0
syncache entries aborted: 0
syncache entries removed due to bad ACK: 0
syncache entries removed due to ICMP unreachable: 0
SYN cookies sent: 0
```

```

SYN cookies received: 0

SACK related statistics:
  SACK recoveries: 1
  SACK retransmitted segments: 0 (0 bytes)
  SACK blocks (options) received: 0
  SACK blocks (options) sent: 0
  SACK scoreboard overflows: 0

Other statistics:
  retransmitted timeout: 0, connections dropped in retransmitted timeout: 0
  persist timeout: 0
  keepalive timeout: 21, keepalive probe: 0
  keepalive timeout, so connections disconnected: 0
  fin_wait_2 timeout, so connections disconnected: 0
  initiated connections: 29, accepted connections: 12, established connections:
23
  closed connections: 50051 (dropped: 0, initiated dropped: 0)
  bad connection attempt: 0
  ignored RSTs in the window: 0
  listen queue overflows: 0
  RTT updates: 3518(attempt segment: 3537)
  correct ACK header predictions: 0
  correct data packet header predictions: 568
  resends due to MTU discovery: 0
  packets dropped due to MD5 authentication failure: 0
  packets that passed MD5 authentication: 0
  sent Keychain-encrypted packets: 0
  packets that passed Keychain authentication: 0
  packets dropped due to Keychain authentication failure: 0

```

Related commands

```
reset tcp statistics
```

display tcp verbose

Use `display tcp verbose` to display detailed information about TCP connections.

Syntax

```
display tcp verbose [ slot slot-number [ pcb pcb-index ] ]
```

Views

Any view

Predefined user roles

```
network-admin
network-operator
```

Parameters

pcb *pcb-index*: Displays detailed TCP connection information for the specified PCB. The index is a hexadecimal string in the range of 1 to ffffffff.

slot *slot-number*: Specifies an IRF member device by its member ID. If you do not specify a member device, this command displays detailed information about TCP connections for all member devices.

Usage guidelines

The detailed TCP connection information includes socket creator, state, option, type, protocol number, source IP address and port number, destination IP address and port number, and connection state.

Examples

Display detailed information about TCP connections.

```
<Sysname> display tcp verbose
```

```
TCP inpcb number: 1(tcpcb number: 1)
```

```
Location: slot: 6 cpu: 0
NSR standby: N/A
Creator: bgpd[199]
State: ISCONNECTED
Options: N/A
Error: 0
Receiving buffer(cc/hiwat/lowat/state): 0 / 65700 / 1 / N/A
Sending buffer(cc/hiwat/lowat/state): 0 / 65700 / 512 / N/A
Type: 1
Protocol: 6
Connection info: src = 192.168.20.200:179 , dst = 192.168.20.14:4181
Inpcb flags: N/A
Inpcb extflag: N/A
Inpcb vflag: INP_IPV4
TTL: 255(minimum TTL: 0)
Connection state: ESTABLISHED
TCP options: TF_REQ_SCALE TF_REQ_TSTMP TF_SACK_PERMIT TF_NSR
NSR state: READY(M)
Send VRF: 0x0
Receive VRF: 0x0
```

Table 5 Command output

Field	Description
TCP inpcb number	Number of TCP IP PCBs.
tcpcb number	Number of TCP PCBs. This field is not displayed if the state of the TCP connection is TIME_WAIT .
Creator	Name of the operation that created the socket. The number in brackets is the process number of the creator.
State	State of the socket.
Options	Socket options.
Error	Error code.

Field	Description
Receiving buffer (cc/hiwat/lowat/state)	Displays receive buffer information in the following order: <ul style="list-style-type: none"> • cc—Used space. • hiwat—Maximum space. • lowat—Minimum space. • state—Buffer state: <ul style="list-style-type: none"> ○ CANTSENDMORE—Unable to send data to the peer. ○ CANTRCVMORE—Unable to receive data from the peer. ○ RCVATMARK—Receiving tag. ○ N/A—None of the above states.
Sending buffer (cc/hiwat/lowat/state)	Displays send buffer information in the following order: <ul style="list-style-type: none"> • cc—Used space. • hiwat—Maximum space. • lowat—Minimum space. • state—Buffer state: <ul style="list-style-type: none"> ○ CANTSENDMORE—Unable to send data to the peer. ○ CANTRCVMORE—Unable to receive data from the peer. ○ RCVATMARK—Receiving tag. ○ N/A—None of the above states.
Type	Socket type: <ul style="list-style-type: none"> • 1—SOCK_STREAM. This socket uses TCP to provide reliable transmission of byte streams. • 2—SOCK_DGRAM. This socket uses UDP to provide datagram transmission. • 3—SOCK_RAW. This socket allows an application to change the next upper-layer protocol header. • N/A—None of the above types.
Protocol	Number of the protocol using the socket.
Connection info	Source IP address and port number, and destination IP address and port number.

Field	Description
Inpcb flags	Flags in the Internet PCB: <ul style="list-style-type: none"> • INP_RECVOPTS—Receives IP options. • INP_RECVRETOPTS—Receives replied IP options. • INP_RECVSTADDR—Receives destination IP address. • INP_HDRINCL—Provides the entire IP header. • INP_REUSEADDR—Reuses the IP address. • INP_REUSEPORT—Reuses the port number. • INP_ANONPORT—Port number not specified. • INP_RECVIF—Records the input interface of the packet. • INP_RECVTTL—Receives TTL of the packet. Only UDP and RawIP support this flag. • INP_DONTFRAG—Sets the Don't Fragment flag. • INP_ROUTER_ALERT—Receives packets with the router alert option. Only RawIP supports this flag. • INP_PROTOCOL_PACKET—Identifies a protocol packet. • INP_RCVLANID—Receives the VLAN ID of the packet. Only UDP and RawIP support this flag. • INP_RCVMACADDR—Receives the MAC address of the frame. • INP_RECVTOS—Receives TOS of the packet. Only UDP and RawIP support this flag. • INP_SYNCPCB—Waits until Internet PCB is synchronized. • N/A—None of the above flags.
Inpcb extflag	Extension flags in the Internet PCB: <ul style="list-style-type: none"> • INP_EXTRCVPVCIDX—Records the PVC index of the received packet. • INP_RCVPWID—Records the PW ID of the received packet. • INP_EXTDONTDROP—Does not drop the received packet. • N/A—None of the above flags.
Inpcb vflag	IP version flags in the Internet PCB: <ul style="list-style-type: none"> • INP_IPV4—IPv4 protocol. • INP_TIMEWAIT—In TIMEWAIT state. • INP_ONESBCAST—Sends broadcast packets. • INP_DROPPED—Protocol dropped flag. • INP_SOCKREF—Strong socket reference. • INP_DONTBLOCK—Do not block synchronization of the Internet PCB. • N/A—None of the above flags.
TTL	TTL value in the Internet PCB.

Field	Description
TCP options	<p>TCP options:</p> <ul style="list-style-type: none"> • TF_MD5SIG—Enables MD5 signature. • TF_NODELAY—Disables the Nagle algorithm that buffers the sent data inside the TCP. • TF_NOOPT—No TCP options. • TF_NOPUSH—Forces TCP to delay sending any TCP data until a full sized segment is buffered in the TCP buffers. • TF_BINDFOREIGNADDR—Binds the peer IP address. • TF_NSR—Enables TCP NSR. • TF_REQ_SCALE—Enables the TCP window scale option. • TF_REQ_TSTMP—Enables the time stamp option. • TF_SACK_PERMIT—Enables the TCP selective acknowledgement option. • TF_ENHANCED_AUTH—Enables the enhanced authentication option.
NSR state	<p>State of the TCP connections.</p> <p>Between the parentheses is the role of the connection:</p> <ul style="list-style-type: none"> • M—Main connection. • S—Standby connection.
Send VRF	VRF from which packets are sent.
Receive VRF	VRF from which packets are received.

display udp

Use `display udp` to display brief information about UDP connections.

Syntax

```
display udp [ slot slot-number ]
```

Views

Any view

Predefined user roles

network-admin

network-operator

Parameters

`slot slot-number`: Specifies an IRF member device by its member ID. If you do not specify a member device, this command displays brief information about UDP connections for all member devices.

Usage guidelines

Brief UDP connection information includes local IP address and port number, and peer IP address and port number.

Examples

Display brief information about UDP connections.

```
<Sysname> display udp
```

```
Local Addr:port      Foreign Addr:port      Slot  PCB
0.0.0.0:69          0.0.0.0:0              1     0x0000000000000003
```

Table 6 Command output

Field	Description
Local Addr:port	Local IP address and port number.
Foreign Addr:port	Peer IP address and port number.
PCB	PCB index.

display udp statistics

Use `display udp statistics` to display UDP traffic statistics.

Syntax

```
display udp statistics [ slot slot-number ]
```

Views

Any view

Predefined user roles

network-admin
network-operator

Parameters

`slot slot-number`: Specifies an IRF member device by its member ID. If you do not specify a member device, this command displays UDP traffic statistics for all member devices.

Usage guidelines

UDP traffic statistics include information about received and sent UDP packets.

Examples

```
# Display UDP traffic statistics.
<Sysname> display udp statistics
Received packets:
  Total: 240
  checksum error: 0, no checksum: 0
  shorter than header: 0, data length larger than packet: 0
  no socket on port(unicast): 0
  no socket on port(broadcast/multicast): 240
  not delivered, input socket full: 0
Sent packets:
  Total: 0
```

Related commands

```
reset udp statistics
```

display udp verbose

Use `display udp verbose` to display detailed information about UDP connections.

Syntax

```
display udp verbose [ slot slot-number [ pcb pcb-index ] ]
```

Views

Any view

Predefined user roles

network-admin

network-operator

Parameters

pcb *pcb-index*: Displays detailed UDP connection information for the specified PCB. The index is a hexadecimal string in the range of 1 to ffffffff.

slot *slot-number*: Specifies an IRF member device by its member ID. If you do not specify a member device, this command displays detailed information about UDP connections for all member devices.

Usage guidelines

The detailed information includes socket creator, status, option, type, protocol number, source IP address and port number, and destination IP address and port number for UDP connections.

Examples

Display detailed UDP connection information.

```
<Sysname> display udp verbose
```

```
Total UDP socket number: 1
```

```
Location: slot: 6 cpu: 0
```

```
Creator: sock_test_mips[250]
```

```
State: N/A
```

```
Options: N/A
```

```
Error: 0
```

```
Receiving buffer(cc/hiwat/lowat/drop/state): 0 / 41600 / 1 / 0 / N/A
```

```
Sending buffer(cc/hiwat/lowat/state): 0 / 9216 / 512 / N/A
```

```
Type: 2
```

```
Protocol: 17
```

```
Connection info: src = 0.0.0.0:69, dst = 0.0.0.0:0
```

```
Inpcb flags: N/A
```

```
Inpcb extflag: N/A
```

```
Inpcb vflag: INP_IPV4
```

```
TTL: 255(minimum TTL: 0)
```

```
Send VRF: 0xffff
```

```
Receive VRF: 0xffff
```

Table 7 Command output

Field	Description
Total UDP socket number	Total number of UDP sockets.
Creator	Name of the operation that created the socket. The number in brackets is the process number of the creator.
State	Socket state.
Options	Socket option.
Error	Error code.

Field	Description
Receiving buffer(cc/hiwat/lowat/drop/state)	<p>Displays receive buffer information in the following order:</p> <ul style="list-style-type: none"> • cc—Used space. • hiwat—Maximum space. • lowat—Minimum space. • drop—Number of dropped packets. • state—Buffer state: <ul style="list-style-type: none"> ○ CANTSENDMORE—Unable to send data to the peer. ○ CANTRCVMORE—Unable to receive data from the peer. ○ RCVATMARK—Receiving tag. ○ N/A—None of the above states.
Sending buffer(cc/hiwat/lowat/state)	<p>Displays send buffer information in the following order:</p> <ul style="list-style-type: none"> • cc—Used space. • hiwat—Maximum space. • lowat—Minimum space. • state—Buffer state: <ul style="list-style-type: none"> ○ CANTSENDMORE—Unable to send data to the peer. ○ CANTRCVMORE—Unable to receive data from the peer. ○ RCVATMARK—Receiving tag. ○ N/A—None of the above states.
Type	<p>Socket type:</p> <ul style="list-style-type: none"> • 1—SOCK_STREAM. This socket uses TCP to provide reliable transmission of byte streams. • 2—SOCK_DGRAM. This socket uses UDP to provide datagram transmission. • 3—SOCK_RAW. This socket allows an application to change the next upper-layer protocol header. • N/A—None of the above types.
Protocol	Number of the protocol using the socket.
Inpcb flags	<p>Flags in the Internet PCB:</p> <ul style="list-style-type: none"> • INP_RECVOPTS—Receives IP options. • INP_RECVRETOPTS—Receives replied IP options. • INP_RECVDSTADDR—Receives destination IP address. • INP_HDRINCL—Provides the entire IP header. • INP_REUSEADDR—Reuses the IP address. • INP_REUSEPORT—Reuses the port number. • INP_ANONPORT—Port number not specified. • INP_RECVIF—Records the input interface of the packet. • INP_RECVTTL—Receives TTL of the packet. Only UDP and RawIP support this flag. • INP_DONTFRAG—Sets the Don't Fragment flag. • INP_ROUTER_ALERT—Receives packets with the router alert option. Only RawIP supports this flag. • INP_PROTOCOL_PACKET—Identifies a protocol packet. • INP_RCVVLANID—Receives the VLAN ID of the packet. Only UDP and RawIP support this flag. • INP_RCVMACADDR—Receives the MAC address of the frame. • INP_RECVTOS—Receives TOS of the packet. Only UDP and RawIP support this flag. • INP_SYNCPCB—Waits until Internet PCB is synchronized. • N/A—None of the above flags.

Field	Description
Inpcb extflag	Extension flags in the Internet PCB: <ul style="list-style-type: none"> • INP_EXTRCVPVCIDX—Records the PVC index of the received packet. • INP_RCVPWID—Records the PW ID of the received packet. • N/A—None of the above flags.
Inpcb vflag	IP version flags in the Internet PCB: <ul style="list-style-type: none"> • INP_IPV4—IPv4 protocol. • INP_TIMEWAIT—In TIMEWAIT state. • INP_ONESBCAST—Sends broadcast packets. • INP_DROPPED—Protocol dropped flag. • INP SOCKREF—Strong socket reference. • INP_DONTBLOCK—Do not block synchronization of the Internet PCB. • N/A—None of the above flags.
TTL	TTL value in the Internet PCB.
Send VRF	VRF from which packets are sent.
Receive VRF	VRF from which packets are received.

ip forward-broadcast

Use `ip forward-broadcast` to enable an interface to forward directed broadcast packets destined for the directly connected network.

Use `undo ip forward-broadcast` to disable an interface from forwarding directed broadcast packets destined for the directly connected network.

Syntax

```
ip forward-broadcast [ acl acl-number ]
undo ip forward-broadcast
```

Default

An interface cannot forward directed broadcasts destined for the directly connected network.

Views

Interface view

Predefined user roles

network-admin

Parameters

acl *acl-number*: Specifies an ACL by its number. The interface forwards only the directed broadcasts permitted by the ACL. The value range for basic ACLs is 2000 to 2999. The value range for advanced ACLs is 3000 to 3999.

Usage guidelines

A directed broadcast packet is destined for all hosts on a specific network. In the destination IP address of the directed broadcast, the network ID identifies the target network, and the host ID is made up of all ones.

If an interface is allowed to forward directed broadcasts destined for the directly connected network, hackers can exploit this vulnerability to attack the target network. In some scenarios, however, an interface must send such directed broadcast packets to support UDP helper and Wake on LAN.

The command enables the interface to forward directed broadcast packets that are destined for the directly connected network and are received from another subnet to support Wake on LAN. Wake on LAN sends the directed broadcasts to wake up the hosts on the target network.

Examples

```
# Enable VLAN-interface 2 to forward directed broadcast packets destined for the directly connected network.
```

```
<Sysname> system-view
[Sysname] interface vlan-interface 2
[Sysname-Vlan-interface2] ip forward-broadcast
```

ip icmp error-interval

Use **ip icmp error-interval** to set the interval for tokens to arrive in the bucket and the bucket size for ICMP error messages.

Use **undo ip icmp error-interval** to restore the default.

Syntax

```
ip icmp error-interval interval [ bucketsize ]
undo ip icmp error-interval
```

Default

A token is placed in the bucket every 100 milliseconds and the bucket allows a maximum of 10 tokens.

Views

System view

Predefined user roles

network-admin

Parameters

interval: Specifies the interval for tokens to arrive in the bucket. The value range is 0 to 2147483647 milliseconds. To disable the ICMP rate limit, set the value to 0.

bucketsize: Specifies the maximum number of tokens allowed in the bucket. The value range is 1 to 200.

Usage guidelines

This command limits the rate at which ICMP error messages are sent. Use this command to avoid sending excessive ICMP error messages within a short period that might cause network congestion. A token bucket algorithm is used with one token representing one ICMP error message.

A token is placed in the bucket at intervals until the maximum number of tokens that the bucket can hold is reached.

A token is removed from the bucket when an ICMP error message is sent. When the bucket is empty, ICMP error messages are not sent until a new token is placed in the bucket.

Examples

```
# Set the interval to 200 milliseconds for tokens to arrive in the bucket and the bucket size to 40 tokens for ICMP error messages.
```

```
<Sysname> system-view
```

```
[Sysname] ip icmp error-interval 200 40
```

ip icmp source

Use **ip icmp source** to specify the source address for outgoing ICMP packets.

Use **undo ip icmp source** to remove the specified source address for outgoing ICMP packets.

Syntax

```
ip icmp source [ vpn-instance vpn-instance-name ] ip-address  
undo ip icmp source [ vpn-instance vpn-instance-name ]
```

Default

No source address is specified for outgoing ICMP packets. The device uses the IP address of the sending interface as the source IP address for outgoing ICMP packets.

Views

System view

Predefined user roles

network-admin

Parameters

vpn-instance vpn-instance-name: Specifies an MPLS L3VPN instance to which the specified address belongs. The *vpn-instance-name* argument represents the VPN instance name, a case-sensitive string of 1 to 31 characters. The specified VPN instance must exist. If you do not specify a VPN instance, the *ip-address* argument specifies an IP address on the public network.

ip-address: Specifies an IP address.

Usage guidelines

It is a good practice to specify the IP address of the loopback interface as the source IP address for outgoing ping echo request and ICMP error messages. This feature helps users to locate the sending device easily.

Examples

```
# Specify 1.1.1.1 as the source address for outgoing ICMP packets.  
<Sysname> system-view  
[Sysname] ip icmp source 1.1.1.1
```

ip mtu

Use **ip mtu** to set the interface MTU for IPv4 packets. The setting defines the largest size of an IPv4 packet that an interface can transmit without fragmentation.

Use **undo ip mtu** to restore the default.

Syntax

```
ip mtu mtu-size  
undo ip mtu
```

Default

The interface MTU is not set.

Views

Interface view

Predefined user roles

network-admin

Parameters

mtu-size: Specifies the MTU in bytes. The value range for the *mtu-size* argument is 128 to 1500.

Usage guidelines

When a packet exceeds the MTU of the sending interface, the device processes the packet in one of the following ways:

- If the packet disallows fragmentation, the device discards it.
- If the packet allows fragmentation, the device fragments it and forwards the fragments.

Fragmentation and reassembling consume system resources, so set an appropriate MTU to avoid fragmentation.

If an interface supports both the `mtu` and `ip mtu` commands, the device fragments a packet based on the MTU set by the `ip mtu` command.

Examples

```
# Set the interface MTU to 1280 bytes on VLAN-interface 100.
<Sysname> system-view
[Sysname] interface vlan-interface 100
[Sysname-Vlan-interface100] ip mtu 1280
```

ip reassemble local enable

Use `ip reassemble local enable` to enable IPv4 local fragment reassembly.

Use `undo ip reassemble local enable` to disable local fragment reassembly.

Syntax

```
ip reassemble local enable
undo ip reassemble local enable
```

Default

IPv4 local fragment reassembly is disabled.

Views

System view

Predefined user roles

network-admin

Usage guidelines

Use this feature on a multichassis IRF fabric to improve fragment reassembly efficiency. This feature enables a subordinate to reassemble the IPv4 fragments of a packet if all the fragments arrive at it. If this feature is disabled, all IPv4 fragments are delivered to the master device for reassembly. The feature applies only to fragments destined for the same subordinate.

Examples

```
# Enable IPv4 local fragment reassembly.
```

```
<Sysname> system-view
[Sysname] ip reassemble local enable
```

ip redirects enable

Use **ip redirects enable** to enable sending ICMP redirect messages.

Use **undo ip redirects enable** to disable sending ICMP redirect messages.

Syntax

```
ip redirects enable
undo ip redirects enable
```

Default

Sending ICMP redirect messages is disabled.

Views

System view

Predefined user roles

network-admin

Usage guidelines

ICMP redirect messages simplify host management and enable hosts to gradually optimize their routing tables.

A host that has only one route destined for the default gateway sends all packets to the default gateway. The default gateway sends an ICMP redirect message to inform the host of a correct next hop by following these rules:

- The receiving and sending interfaces are the same.
- The selected route is not created or modified by any ICMP redirect messages.
- The selected route is not destined for 0.0.0.0.
- There is no source route option in the received packet.

Examples

```
# Enable sending ICMP redirect messages.
<Sysname> system-view
[Sysname] ip redirects enable
```

ip ttl-expires enable

Use **ip ttl-expires enable** to enable sending ICMP time exceeded messages.

Use **undo ip ttl-expires enable** to disable sending ICMP time exceeded messages.

Syntax

```
ip ttl-expires enable
undo ip ttl-expires enable
```

Default

Sending ICMP time exceeded messages is disabled.

Views

System view

Predefined user roles

network-admin

Usage guidelines

A device sends ICMP time exceeded messages by following these rules:

- The device sends an ICMP TTL exceeded in transit message to the source when the following conditions are met:
 - The received packet is not destined for the device.
 - The TTL field of the packet is 1.
- When the device receives the first fragment of an IP datagram destined for the device itself, it starts a timer. If the timer expires before all the fragments of the datagram are received, the device sends an ICMP fragment reassembly time exceeded message to the source.

A device disabled from sending ICMP time exceeded messages does not send ICMP TTL exceeded in transit messages but can still send ICMP fragment reassembly time exceeded messages.

Examples

```
# Enable sending ICMP time exceeded messages.
```

```
<Sysname> system-view
```

```
[Sysname] ip ttl-expires enable
```

ip unreachable enable

Use **ip unreachable enable** to enable sending ICMP destination unreachable messages.

Use **undo ip unreachable enable** to disable sending ICMP destination unreachable messages.

Syntax

```
ip unreachable enable
```

```
undo ip unreachable enable
```

Default

Sending ICMP destination unreachable messages is disabled.

Views

System view

Predefined user roles

network-admin

Usage guidelines

A device sends ICMP destination unreachable messages by following these rules:

- The device sends the source an ICMP network unreachable message when the following conditions are met:
 - The received packet does not match any route.
 - No default route exists in the routing table.
- The device sends the source an ICMP protocol unreachable message when the following conditions are met:
 - The received packet is destined for the device.
 - The transport layer protocol of the packet is not supported by the device.

- The device sends the source an ICMP port unreachable message when the following conditions are met:
 - The received UDP packet is destined for the device.
 - The packet's port number does not match the running process.
- The device sends the source an ICMP source route failed message when the following conditions are met:
 - The source uses Strict Source Routing to send packets.
 - The intermediate device finds that the next hop specified by the source is not directly connected.
- The device sends the source an ICMP fragmentation needed and DF set message when the following conditions are met:
 - The MTU of the sending interface is smaller than the packet.
 - The packet has Don't Fragment set.

Examples

```
# Enable sending ICMP destination unreachable messages.
<Sysname> system-view
[Sysname] ip unreachable enable
```

reset ip statistics

Use **reset ip statistics** to clear IP traffic statistics.

Syntax

```
reset ip statistics [ slot slot-number ]
```

Views

User view

Predefined user roles

network-admin

Parameters

slot *slot-number*: Specifies an IRF member device by its member ID. If you do not specify a member device, this command clears IP traffic statistics for all member devices.

Usage guidelines

Use this command to clear history IP traffic statistics before you collect IP traffic statistics for a time period.

Examples

```
# Clear IP traffic statistics.
<Sysname> reset ip statistics
```

Related commands

```
display ip interface
display ip statistics
```

reset tcp statistics

Use **reset tcp statistics** to clear TCP traffic statistics.

Syntax

```
reset tcp statistics
```

Views

User view

Predefined user roles

network-admin

Examples

```
# Clear TCP traffic statistics.  
<Sysname> reset tcp statistics
```

Related commands

```
display tcp statistics
```

reset udp statistics

Use `reset udp statistics` to clear UDP traffic statistics.

Syntax

```
reset udp statistics
```

Views

User view

Predefined user roles

network-admin

Examples

```
# Clear UDP traffic statistics.  
<Sysname> reset udp statistics
```

Related commands

```
display udp statistics
```

tcp mss

Use `tcp mss` to set the TCP maximum segment size (MSS).

Use `undo tcp mss` to restore the default.

Syntax

```
tcp mss value  
undo tcp mss
```

Default

The TCP MSS is not set.

Views

Interface view

Predefined user roles

network-admin

Parameters

value: Specifies the TCP MSS in bytes. The value range for this argument is 128 to 1460.

Usage guidelines

The MSS option informs the receiver of the largest segment that the sender can accept. Each end announces its MSS during TCP connection establishment. If the size of a TCP segment is smaller than the MSS of the receiver, TCP sends the TCP segment without fragmentation. If not, TCP fragments the segment according to the receiver's MSS.

If you set the TCP MSS on an interface, the size of each TCP segment received or sent on the interface cannot exceed the MSS value.

This configuration takes effect only on TCP connections that are established after the configuration and not on the TCP connections that already exist.

This configuration is effective only on IP packets.

Examples

```
# Set the TCP MSS to 300 bytes on VLAN-interface 100.
<Sysname> system-view
[Sysname] interface vlan-interface 100
[Sysname-Vlan-interface100] tcp mss 300
```

tcp path-mtu-discovery

Use **tcp path-mtu-discovery** to enable TCP path MTU discovery.

Use **undo tcp path-mtu-discovery** to disable TCP path MTU discovery.

Syntax

```
tcp path-mtu-discovery [ aging age-time | no-aging ]
undo tcp path-mtu-discovery
```

Default

TCP path MTU discovery is disabled.

Views

System view

Predefined user roles

network-admin

Parameters

aging *age-time*: Specifies the aging time for the path MTU, in the range of 10 to 30 minutes. The default aging time is 10 minutes.

no-aging: Does not age out the path MTU.

Usage guidelines

After you enable TCP path MTU discovery, all new TCP connections detect the path MTU. The device uses the path MTU to calculate the MSS to avoid IP fragmentation.

After you disable TCP path MTU discovery, the system stops all path MTU timers. The TCP connections established later do not detect the path MTU, but the TCP connections previously established still can detect the path MTU.

Examples

```
# Enable TCP path MTU discovery and set the path MTU aging time to 20 minutes.
```

```
<Sysname> system-view
[Sysname] tcp path-mtu-discovery aging 20
```

tcp syn-cookie enable

Use `tcp syn-cookie enable` to enable SYN Cookie to protect the device from SYN flood attacks.

Use `undo tcp syn-cookie enable` to disable SYN Cookie.

Syntax

```
tcp syn-cookie enable
undo tcp syn-cookie enable
```

Default

SYN Cookie is disabled.

Views

System view

Predefined user roles

network-admin

Usage guidelines

A TCP connection is established through a three-way handshake:

1. The sender sends a SYN packet to the server.
2. The server receives the SYN packet, establishes a TCP semi-connection in SYN_RECEIVED state, and replies with a SYN ACK packet to the sender.
3. The sender receives the SYN ACK packet and replies with an ACK packet. Then, a TCP connection is established.

An attacker can exploit this mechanism to mount SYN flood attacks. The attacker sends a large number of SYN packets, but they do not respond to the SYN ACK packets from the server. As a result, the server establishes a large number of TCP semi-connections and cannot handle normal services.

SYN Cookie can protect the server from SYN flood attacks. When the server receives a SYN packet, it responds to the request with a SYN ACK packet without establishing a TCP semi-connection.

The server establishes a TCP connection and enters ESTABLISHED state only when it receives an ACK packet from the sender.

Examples

```
# Enable SYN Cookie.
<Sysname> system-view
[Sysname] tcp syn-cookie enable
```

tcp timer fin-timeout

Use `tcp timer fin-timeout` to set the TCP FIN wait timer.

Use `undo tcp timer fin-timeout` to restore the default.

Syntax

```
tcp timer fin-timeout time-value
undo tcp timer fin-timeout
```

Default

The TCP FIN wait timer is 675 seconds.

Views

System view

Predefined user roles

network-admin

Parameters

time-value: Specifies the TCP FIN wait timer in the range of 76 to 3600 seconds.

Usage guidelines

TCP starts the FIN wait timer when the state of a TCP connection changes to FIN_WAIT_2. If no FIN packet is received within the timer interval, the TCP connection is terminated.

If a FIN packet is received, TCP changes the connection state to TIME_WAIT. If a non-FIN packet is received, TCP restarts the timer and tears down the connection when the timer expires.

Examples

```
# Set the TCP FIN wait timer to 800 seconds.
<Sysname> system-view
[Sysname] tcp timer fin-timeout 800
```

tcp timer syn-timeout

Use `tcp timer syn-timeout` to set the TCP SYN wait timer.

Use `undo tcp timer syn-timeout` to restore the default.

Syntax

```
tcp timer syn-timeout time-value
undo tcp timer syn-timeout
```

Default

The TCP SYN wait timer is 75 seconds.

Views

System view

Predefined user roles

network-admin

Parameters

time-value: Specifies the TCP SYN wait timer in the range of 2 to 600 seconds.

Usage guidelines

TCP starts the SYN wait timer after sending a SYN packet. Within the SYN wait timer if no response is received or the upper limit on TCP connection tries is reached, TCP fails to establish the connection.

Examples

```
# Set the TCP SYN wait timer to 80 seconds.
<Sysname> system-view
[Sysname] tcp timer syn-timeout 80
```

tcp window

Use `tcp window` to set the size of the TCP receive/send buffer.

Use `undo tcp window` to restore the default.

Syntax

```
tcp window window-size
```

```
undo tcp window
```

Default

The size of the TCP receive/send buffer is 63 KB.

Views

System view

Predefined user roles

network-admin

Parameters

window-size: Specifies the size of the TCP receive/send buffer, in the range of 1 to 64 KB.

Examples

```
# Set the size of the TCP receive/send buffer to 3 KB.
```

```
<Sysname> system-view
```

```
[Sysname] tcp window 3
```