

Contents

Configuring tunneling	1
About tunneling	1
Supported tunneling technologies.....	1
Restrictions and guidelines: Tunnel interface configuration.....	1
Prerequisites for tunnel configuration.....	1
Configuring a tunnel interface	1
About tunnel interface configuration.....	1
Tunnel interface configuration tasks at a glance.....	1
Creating a tunnel interface	2
Specifying traffic processing slots for the tunnel interface	3
Configuring parameters for tunneled packets	3
Restoring the default settings of the tunnel interface	3
Adding TUNNEL to the PHY_UPDOWN log mnemonic for tunnel interfaces.....	4
Display and maintenance commands for tunnel interface configuration.....	4
Troubleshooting tunnel interface configuration	5
Tunnel interface not up	5
IPv6 over IPv4 tunneling	6
About IPv6 over IPv4 tunneling.....	6
Implementation.....	6
Tunnel modes	6
IPv6 over IPv4 tunneling tasks at a glance	8
Configuring an IPv6 over IPv4 manual tunnel.....	8
Restrictions and guidelines	8
Procedure.....	9
Example: Configuring an IPv6 over IPv4 manual tunnel.....	9
Configuring a 6to4 tunnel.....	12
Restrictions and guidelines	12
Procedure.....	12
Example: Configuring a 6to4 tunnel.....	12
Example: Configuring 6to4 relay	15
Configuring an ISATAP tunnel	17
Restrictions and guidelines	17
Procedure.....	18
Example: Configuring an ISATAP tunnel	18
Enabling dropping IPv6 packets that use IPv4-compatible IPv6 addresses	20
IPv4 over IPv4 tunneling	22
About IPv4 over IPv4 tunneling.....	22
Restrictions and guidelines: IPv4 over IPv4 tunnel configuration	22
Configuring an IPv4 over IPv4 tunnel	23
IPv4 over IPv4 tunnel configuration examples	24
Example: Configuring an IPv4 over IPv4 tunnel.....	24
IPv4 over IPv6 tunneling	27
About IPv4 over IPv6 tunneling.....	27
Configuring an IPv4 over IPv6 tunnel	27
Restrictions and guidelines	27
Procedure.....	28
Example: Configuring an IPv4 over IPv6 tunnel.....	28
IPv6 over IPv6 tunneling	31
About IPv6 over IPv6 tunneling.....	31
Restrictions and guidelines: IPv6 over IPv6 tunnel configuration	31
IPv6 over IPv6 tunnel configuration tasks at a glance	32
Configuring an IPv6 over IPv6 tunnel	32
Enabling dropping IPv6 packets that use IPv4-compatible IPv6 addresses	32

IPv6 over IPv6 tunnel configuration examples.....	33
Example: Configuring an IPv6 over IPv6 tunnel.....	33

Configuring tunneling

This chapter describes tunnel interface configuration. For information about tunnel modes, see the subsequent chapters.

About tunneling

Tunneling encapsulates the packets of a network protocol within the packets of a second network protocol and transfers them over a virtual point-to-point connection. The virtual connection is called a tunnel. Packets are encapsulated at the tunnel source and de-encapsulated at the tunnel destination.

Supported tunneling technologies

Tunneling supports the following technologies:

- GRE tunneling. For more information, see "Configuring GRE."
- MPLS TE tunneling. For more information, see *MPLS Configuration Guide*.
- VXLAN tunneling and VXLAN-DCI tunneling. For more information, see *VXLAN Configuration Guide*.
- IPv6 over IPv4 tunneling, IPv4 over IPv4 tunneling, and IPv4/IPv6 over IPv6 tunneling.

Restrictions and guidelines: Tunnel interface configuration

Do not specify the same tunnel source and destination addresses for the tunnel interfaces on the same device.

Prerequisites for tunnel configuration

The device cannot directly route a tunneled packet based on its destination address. The packet is sent to a tunnel-type service loopback group, which then delivers the packet to the forwarding module for Layer 3 forwarding. For the tunnel interface to forward and receive packets, you must configure a tunnel-type service loopback group on the device. For information about service loopback group, see *Layer 2—LAN Switching Configuration Guide*.

Configuring a tunnel interface

About tunnel interface configuration

Configure a tunnel interface (Layer 3 virtual interface) at both ends of a tunnel. The devices use the tunnel interface to identify, process, and send packets for the tunnel.

Tunnel interface configuration tasks at a glance

To configure a tunnel interface, perform the following tasks:

1. [Creating a tunnel interface](#)
2. (Optional.) [Specifying traffic processing slots for the tunnel interface](#)
3. (Optional.) [Configuring parameters for tunneled packets](#)
4. (Optional.) [Restoring the default settings of the tunnel interface](#)
5. (Optional.) [Adding TUNNEL to the PHY_UPDOWN log mnemonic for tunnel interfaces](#)

Creating a tunnel interface

1. Enter system view.
system-view
2. Create a tunnel interface, specify the tunnel mode, and enter tunnel interface view.
interface tunnel *number* **mode** { **gre** [**ipv6**] | **ipv4-ipv4** | **ipv6** | **ipv6-ipv4** [**6to4** | **isatap**] | **mpls-te** | **vxlan** | **vxlan-dci** }
For packet tunneling to succeed, the two ends of a tunnel must use the same tunnel mode.
3. Configure a source address or source interface for the tunnel interface.
source { *ipv4-address* | *ipv6-address* | *interface-type interface-number* }
By default, no source address or source interface is configured for the tunnel interface.
If you specify a source address, it is used as the source address of tunneled packets.
If you specify a source interface, the primary IP address of this interface is used as the source IP address of tunneled packets.
4. Configure a destination address for the tunnel interface.
destination { *ipv4-address* | *ipv6-address* }
By default, no destination address is configured for the tunnel interface.
The tunnel destination address must be the IP address of the receiving interface on the tunnel peer. It is used as the destination IP address of tunneled packets.
5. (Optional.) Configure a description for the interface.
description *text*
By default, the description for a tunnel interface is **Tunnel** *number* **Interface**.
6. (Optional.) Set the MTU of the tunnel interface.
mtu *size*
The default settings are as follows:
 - If the tunnel interface has never been up, the MTU is 64000 bytes.
 - If the tunnel interface is up, its MTU is identical to the outgoing interface's MTU minus the length of the tunnel headers. The outgoing interface is automatically obtained through routing table lookup based on the tunnel destination address.
7. (Optional.) Set the expected bandwidth for the tunnel interface.
bandwidth *bandwidth-value*
The default expected bandwidth (in kbps) is the interface maximum rate divided by 1000.
The expected bandwidth is an informational parameter used only by higher-layer protocols for calculation. You cannot adjust the actual bandwidth of an interface by using this command.
8. Bring up the tunnel interface.
undo shutdown
By default, a tunnel interface is not administratively down.

Specifying traffic processing slots for the tunnel interface

About traffic processing slots

Specify a traffic processing slot if a feature (for example, IPsec antireplay) requires that all traffic on a tunnel interface be processed on the same slot.

Procedure

1. Enter system view.
system-view
2. Enter tunnel interface view.
interface tunnel *number*
3. Specify a traffic processing slot for the tunnel interface.
service slot *slot-number*
By default, no traffic processing slot is specified.

Configuring parameters for tunneled packets

1. Enter system view.
system-view
2. Enter tunnel interface view.
interface tunnel *number*
3. Set the ToS for tunneled packets.
tunnel tos *tos-value*
The default setting is the same as the ToS of the original packets.
4. Set the TTL for tunneled packets.
tunnel ttl *ttl-value*
The default TTL for tunneled packets is 255.

Restoring the default settings of the tunnel interface

Restrictions and guidelines

CAUTION:

This operation might interrupt ongoing network services. Make sure you are fully aware of the impact of this operation when you perform it on a live network.

This operation might fail to restore the default settings for some commands for reasons such as command dependencies or system restrictions. Use the **display this** command in interface view to identify these commands. Use their **undo** forms or follow the command reference to restore their default settings. If your restoration attempt still fails, follow the error message instructions to resolve the problem.

Procedure

1. Enter system view.
system-view
2. Enter tunnel interface view.
interface tunnel *number*
3. Restore the default settings of the tunnel interface.

default

Adding TUNNEL to the PHY_UPDOWN log mnemonic for tunnel interfaces

About adding TUNNEL to the PHY_UPDOWN log mnemonic for tunnel interfaces

This feature adds the TUNNEL string to the PHY_UPDOWN log mnemonic for tunnel interfaces. Use this feature if you want to identify the interface state change logs for tunnel interfaces by using a regular expression that contains the TUNNEL string.

A tunnel interface state change log without the TUNNEL string in the mnemonic:

```
%Jan 8 18:45:33:621 2011 Sysname IFNET/3/PHY_UPDOWN: Physical state on the interface Tunnell changed to down.
```

A tunnel interface state change log with the TUNNEL string in the mnemonic:

```
%Jan 8 18:45:33:621 2011 Sysname IFNET/3/TUNNEL_PHY_UPDOWN: Physical state on the interface Tunnell changed to down.
```

Procedure

1. Enter system view.
system-view
2. Add the TUNNEL string to the PHY_UPDOWN log mnemonic for tunnel interfaces.
tunnel log updown with-tag

By default, the PHY_UPDOWN log mnemonic for tunnel interfaces does not contain the TUNNEL string.

Display and maintenance commands for tunnel interface configuration

Execute **display** commands in any view and **reset** commands in user view.

Task	Command	Remarks
Display information about tunnel interfaces.	display interface [tunnel [<i>number</i>]] [brief [description down]]	N/A
Display IPv6 information on tunnel interfaces.	display ipv6 interface [tunnel [<i>number</i>]] [brief]	For more information about this command, see IPv6 basics in <i>Layer 3—IP Services Command Reference</i> .
Clear statistics on tunnel interfaces.	reset counters interface [tunnel [<i>number</i>]]	N/A
Clear IPv6 statistics on tunnel interfaces.	reset ipv6 statistics [slot <i>slot-number</i>]	For more information about this command, see IPv6 basics in <i>Layer 3—IP Services Command Reference</i> .

Troubleshooting tunnel interface configuration

Tunnel interface not up

Symptom

A tunnel interface configured with related parameters such as tunnel source address, tunnel destination address, and tunnel mode cannot come up.

Analysis

The physical interface of the tunnel does not come up, or the tunnel destination is unreachable.

Solution

1. To resolve the problem:
 - Use the **display interface** or **display ipv6 interface** command to verify that the physical interface of the tunnel is up. If the physical interface is down, check the network connection.
 - Use the **display ipv6 routing-table** or **display ip routing-table** command to verify that the tunnel destination is reachable. If the route is not available, configure a route to reach the tunnel destination.
2. If the problem persists, contact H3C Support.

IPv6 over IPv4 tunneling

About IPv6 over IPv4 tunneling


Implementation

IPv6 over IPv4 tunneling enables isolated IPv6 networks to communicate, as shown in [Figure 1](#).

NOTE:

The devices at both ends of an IPv6 over IPv4 tunnel must support the IPv4/IPv6 dual stack.

Figure 1 IPv6 over IPv4 tunnel



The IPv6 over IPv4 tunnel processes packets by using the following steps:

1. A host in the IPv6 network sends an IPv6 packet to Device A at the tunnel source.
2. After Device A receives the IPv6 packet, it processes the packet as follows:
 - a. Searches the routing table to identify the outgoing interface for the IPv6 packet.
The outgoing interface is the tunnel interface, so Device A knows that the packet needs to be forwarded through the tunnel.
 - b. Adds an IPv4 header to the IPv6 packet and forwards the packet through the physical interface of the tunnel.
In the IPv4 header, the source IPv4 address is the IPv4 address of the tunnel source, and the destination IPv4 address is the IPv4 address of the tunnel destination.
3. Upon receiving the packet, Device B de-encapsulates the packet.
4. If the destination address of the IPv6 packet is itself, Device B forwards it to the upper-layer protocol. If it is not, Device B forwards it according to the routing table.

Tunnel modes

IPv6 over IPv4 tunnels include manually configured tunnels and automatic tunnels, depending on how the IPv4 address of the tunnel destination is obtained.

- **Manually configured tunnel**—The destination IPv4 address of the tunnel cannot be automatically obtained from the destination IPv6 address of an IPv6 packet at the tunnel source. It must be manually configured.

- **Automatic tunnel**—The destination IPv4 address of the tunnel can be automatically obtained from the destination IPv6 address (with an IPv4 address embedded) of an IPv6 packet at the tunnel source.

The source IPv4 addresses for all IPv6 over IPv4 tunnels are manually configured.

According to the way an IPv6 packet is encapsulated, IPv6 over IPv4 tunnels are divided into the modes shown in the following sections.

IPv6 over IPv4 manual tunneling

An IPv6 over IPv4 manual tunnel is a point-to-point link. To establish a manual tunnel, you must manually configure the source and destination addresses of the tunnel at both ends of the tunnel.

Manual tunneling provides the following solutions:

- Connects isolated IPv6 networks over an IPv4 network.
- Connects an IPv6 network and an IPv4/IPv6 dual-stack host over an IPv4 network.

6to4 tunneling

- Ordinary 6to4 tunneling

A 6to4 tunnel is a point-to-multipoint automatic tunnel. It is used to connect multiple isolated IPv6 networks over an IPv4 network.

The ends of a 6to4 tunnel are 6to4 addresses. The address format is 2002:abcd:efgh:subnet number::interface ID/48.

- 2002 is the fixed IPv6 address prefix.
- abcd:efgh represents a 32-bit globally unique IPv4 address in hexadecimal notation.

For example, 1.1.1.1 can be represented by 0101:0101. The IPv4 address identifies a 6to4 network (an IPv6 network where all hosts use 6to4 addresses). The border router of a 6to4 network must have the IPv4 address abcd:efgh configured on the interface connected to the IPv4 network.

- The subnet number identifies a subnet in the 6to4 network.
- The subnet number::interface ID uniquely identifies a host in the 6to4 network.

The destination IPv4 address of a 6to4 tunnel is embedded in the destination 6to4 address. This mechanism enables the device to automatically obtain the tunnel destination address.


6to4 tunneling uses an IPv4 address to identify a 6to4 network. This method overcomes the limitations of automatic IPv4-compatible IPv6 tunneling.

- 6to4 relay

6to4 relay connects a 6to4 network and an IPv6 network that uses an IP prefix other than 2002::/16. A 6to4 relay router is a gateway that forwards packets from a 6to4 network to an IPv6 network.

As shown in [Figure 2](#), 6to4 network Site 1 communicates with IPv6 network Site 3 over a 6to4 tunnel. Configure a static route on the border router (Device A) in the 6to4 network. The next hop address must be the 6to4 address of the 6to4 relay router (Device C). Device A forwards all packets destined for the IPv6 network over the 6to4 tunnel, and Device C then forwards them to the IPv6 network.

Figure 2 Principle of 6to4 tunneling and 6to4 relay



ISATAP tunneling


An ISATAP tunnel is a point-to-multipoint automatic tunnel. It provides a solution to connect an IPv6 host and an IPv6 network over an IPv4 network.

The destination address of an ISATAP tunnel is an ISATAP address. The address format is prefix:0:5EFE:abcd:efgh/64.

- The 64-bit prefix is a valid IPv6 unicast address prefix.
- The abcd:efgh/64 segments represent a 32-bit IPv4 address in hexadecimal notation, which identifies the tunnel destination but does not require global uniqueness.

ISATAP tunnels are mainly used for communication between IPv6 routers or between an IPv6 host and an IPv6 router over an IPv4 network.

Figure 3 Principle of ISATAP tunneling



IPv6 over IPv4 tunneling tasks at a glance

To configure IPv6 over IPv4 tunneling, perform the following tasks:

1. Configuring an IPv6 over IPv4 tunnel
Choose one of the following tasks:
 - [Configuring an IPv6 over IPv4 manual tunnel](#)
 - [Configuring a 6to4 tunnel](#)
 - [Configuring an ISATAP tunnel](#)
2. (Optional.) [Enabling dropping IPv6 packets that use IPv4-compatible IPv6 addresses](#)

Configuring an IPv6 over IPv4 manual tunnel

Restrictions and guidelines

When you perform tasks in this section, follow these restrictions and guidelines:

- The tunnel destination address specified on the local device must be identical with the tunnel source address specified on the tunnel peer device.
- Do not specify the same tunnel source and destination addresses for the tunnel interfaces in the same mode on a device.
- To ensure correct packet forwarding, identify whether the destination IPv6 network and the IPv6 address of the local tunnel interface are on the same subnet. If they are not, configure a static route reaching the destination IPv6 network through the tunnel interface. You can specify the local tunnel interface as the egress interface or specify the IPv6 address of the peer tunnel interface as the next hop in the static route. The route configuration is required on both ends of the tunnel.

For more information about IPv6 static route configuration, see *Layer 3—IP Routing Configuration Guide*.

Procedure


1. Enter system view.
system-view
2. Enter IPv6 over IPv4 manual tunnel interface view.
interface tunnel *number* [mode **ipv6-ipv4]**
3. Specify an IPv6 address for the tunnel interface.
See "Configuring basic IPv6 settings."
4. Configure a source address or source interface for the tunnel interface.
source { *ipv4-address* | *interface-type interface-number* }
By default, no source address or source interface is configured for the tunnel interface.
If you specify a source address, it is used as the source IP address of tunneled packets.
If you specify a source interface, the primary IP address of this interface is used as the source IP address of tunneled packets.
5. Configure a destination address for the tunnel interface.
destination *ipv4-address*
By default, no destination address is configured for the tunnel interface.
The tunnel destination address must be the IP address of the receiving interface on the tunnel peer. It is used as the destination IP address of tunneled packets.
6. (Optional.) Set the DF bit for tunneled packets.
tunnel dfbit enable
By default, the DF bit is not set for tunneled packets.

Example: Configuring an IPv6 over IPv4 manual tunnel

Network configuration

As shown in [Figure 4](#), configure an IPv6 over IPv4 tunnel between Switch A and Switch B so the two IPv6 networks can reach each other over the IPv4 network. Because the tunnel destination IPv4 address cannot be automatically obtained from the destination IPv6 addresses, configure an IPv6 over IPv4 manual tunnel.

Figure 4 Network diagram



Procedure

Make sure Switch A and Switch B have the corresponding VLAN interfaces created and can reach each other through IPv4.

- **Configure Switch A:**

- # Add Twenty-FiveGigE 1/0/2 (the physical interface of the tunnel) to VLAN 100.

```
<SwitchA> system-view
[SwitchA] vlan 100
[SwitchA-vlan100] port twenty-fivegige 1/0/2
[SwitchA-vlan100] quit
```

- # Specify an IPv4 address for VLAN-interface 100.

```
[SwitchA] interface vlan-interface 100
[SwitchA-Vlan-interface100] ip address 192.168.100.1 255.255.255.0
[SwitchA-Vlan-interface100] quit
```

- # Add Twenty-FiveGigE 1/0/1 to VLAN 101.

```
[SwitchA] vlan 101
[SwitchA-vlan101] port twenty-fivegige 1/0/1
[SwitchA-vlan101] quit
```

- # Specify an IPv6 address for VLAN-interface 101.

```
[SwitchA] interface vlan-interface 101
[SwitchA-Vlan-interface101] ipv6 address 3002::1 64
[SwitchA-Vlan-interface101] quit
```

- # Create service loopback group 1, and specify its service type as **tunnel**.

```
[SwitchA] service-loopback group 1 type tunnel
```

- # Add Twenty-FiveGigE 1/0/3 to service loopback group 1.

```
[SwitchA] interface twenty-fivegige 1/0/3
[SwitchA-Twenty-FiveGigE1/0/3] port service-loopback group 1
[SwitchA-Twenty-FiveGigE1/0/3] quit
```

- # Create IPv6 over IPv4 manual tunnel interface Tunnel 0.

```
[SwitchA] interface tunnel 0 mode ipv6-ipv4
```

- # Specify an IPv6 address for the tunnel interface.

```
[SwitchA-Tunnel0] ipv6 address 3001::1/64
```

- # Specify VLAN-interface 100 as the source interface of the tunnel interface.

```
[SwitchA-Tunnel0] source vlan-interface 100
```

- # Specify the destination address for the tunnel interface as the IP address of the VLAN-interface 100 on Switch B.

```
[SwitchA-Tunnel0] destination 192.168.50.1
```

```
[SwitchA-Tunnel0] quit
```

Configure a static route destined for IPv6 network 2 through tunnel 0.

```
[SwitchA] ipv6 route-static 3003:: 64 tunnel 0
```

- **Configure Switch B:**

Add Twenty-FiveGigE 1/0/2 (the physical interface of the tunnel) to VLAN 100.

```
<SwitchB> system-view
```

```
[SwitchB] vlan 100
```

```
[SwitchB-vlan100] port twenty-fivegige 1/0/2
```

```
[SwitchB-vlan100] quit
```

Specify an IPv4 address for VLAN-interface 100.

```
[SwitchB] interface vlan-interface 100
```

```
[SwitchB-Vlan-interface100] ip address 192.168.50.1 255.255.255.0
```

```
[SwitchB-Vlan-interface100] quit
```

Add Twenty-FiveGigE 1/0/1 to VLAN 101.

```
[SwitchB] vlan 101
```

```
[SwitchB-vlan101] port twenty-fivegige 1/0/1
```

```
[SwitchB-vlan101] quit
```

Specify an IPv6 address for VLAN-interface 101.

```
[SwitchB] interface vlan-interface 101
```

```
[SwitchB-Vlan-interface101] ipv6 address 3003::1 64
```

```
[SwitchB-Vlan-interface101] quit
```

Create service loopback group 1, and specify its service type as **tunnel**.

```
[SwitchB] service-loopback group 1 type tunnel
```

Add Twenty-FiveGigE 1/0/3 to service loopback group 1.

```
[SwitchB] interface twenty-fivegige 1/0/3
```

```
[SwitchB-Twenty-FiveGigE1/0/3] port service-loopback group 1
```

```
[SwitchB-Twenty-FiveGigE1/0/3] quit
```

Create IPv6 over IPv4 manual tunnel interface Tunnel 0.

```
[SwitchB] interface tunnel 0 mode ipv6-ipv4
```

Specify an IPv6 address for the tunnel interface.

```
[SwitchB-Tunnel0] ipv6 address 3001::2/64
```

Specify VLAN-interface 100 as the source interface of the tunnel interface.

```
[SwitchB-Tunnel0] source vlan-interface 100
```

Specify the destination address for the tunnel interface as the IP address of VLAN-interface 100 of Switch A.

```
[SwitchB-Tunnel0] destination 192.168.100.1
```

```
[SwitchB-Tunnel0] quit
```

Configure a static route destined for IPv6 network 1 through tunnel 0.

```
[SwitchB] ipv6 route-static 3002:: 64 tunnel 0
```

Verifying the configuration

Use the **display ipv6 interface** command to display tunnel interface status on Switch A and Switch B. Verify that the interface tunnel 0 is up. (Details not shown.)

Verify that Switch B and Switch A can ping the IPv6 address of VLAN-interface 101 of each other. This example uses Switch A.

```
[SwitchA] ping ipv6 3003::1
```

```
Ping6(56 data bytes) 3001::1 --> 3003::1, press CTRL_C to break
```

```
56 bytes from 3003::1, icmp_seq=0 hlim=64 time=45.000 ms
```

```
56 bytes from 3003::1, icmp_seq=1 hlim=64 time=10.000 ms
```

```

56 bytes from 3003::1, icmp_seq=2 hlim=64 time=4.000 ms
56 bytes from 3003::1, icmp_seq=3 hlim=64 time=10.000 ms
56 bytes from 3003::1, icmp_seq=4 hlim=64 time=11.000 ms

--- Ping6 statistics for 3003::1 ---
5 packet(s) transmitted, 5 packet(s) received, 0.0% packet loss
round-trip min/avg/max/std-dev = 4.000/16.000/45.000/14.711 ms

```

Configuring a 6to4 tunnel

Restrictions and guidelines

Follow these guidelines when you configure a 6to4 tunnel:

- You do not need to configure a destination address for a 6to4 tunnel, because the destination IPv4 address is embedded in the 6to4 IPv6 address.
- Do not specify the same source addresses for local tunnel interfaces in the same tunnel mode.
- Automatic tunnels do not support dynamic routing. You must configure a static route destined for the destination IPv6 network if the destination IPv6 network is not in the same subnet as the IPv6 address of the tunnel interface. You can specify the local tunnel interface as the egress interface of the route or specify the IPv6 address of the peer tunnel interface as the next hop of the route. The route configuration is required on both ends of the tunnel. For more information about route configuration, see *Layer 3—IP Routing Configuration Guide*.

Procedure


1. Enter system view.
system-view
2. Enter 6to4 tunnel interface view.
interface tunnel *number* [**mode ipv6-ipv4 6to4**]
3. Specify an IPv6 address for the tunnel interface.
See "Configuring basic IPv6 settings."
4. Configure a source address or source interface for the tunnel interface.
source { *ipv4-address* | *interface-type interface-number* }
By default, no source address or source interface is configured for the tunnel interface.
If you specify a source address, it is used as the source IP address of tunneled packets.
If you specify a source interface, the primary IP address of this interface is used as the source IP address of tunneled packets.
5. (Optional.) Set the DF bit for tunneled packets.
tunnel dfbit enable
By default, the DF bit is not set for tunneled packets.

Example: Configuring a 6to4 tunnel

Network configuration

As shown in [Figure 5](#), configure a 6to4 tunnel between 6to4 switches Switch A and Switch B so the two hosts can reach each other over the IPv4 network.

Figure 5 Network diagram



Requirements analysis

To enable communication between 6to4 networks, configure 6to4 addresses for 6to4 switches and hosts in the 6to4 networks.

- The IPv4 address of VLAN-interface 100 on Switch A is 2.1.1.1/24, and the corresponding 6to4 prefix is 2002:0201:0101::/48. Host A must use this prefix.
- The IPv4 address of VLAN-interface 100 on Switch B is 5.1.1.1/24, and the corresponding 6to4 prefix is 2002:0501:0101::/48. Host B must use this prefix.

Procedure

Make sure Switch A and Switch B have the corresponding VLAN interfaces created and can reach each other through IPv4.

- Configure Switch A:
 - # Add Twenty-FiveGigE 1/0/2 (the physical interface of the tunnel) to VLAN 100.


```
<SwitchA> system-view
[SwitchA] vlan 100
[SwitchA-vlan100] port twenty-fivegige 1/0/2
[SwitchA-vlan100] quit
```
 - # Specify an IPv4 address for VLAN-interface 100.


```
[SwitchA] interface vlan-interface 100
[SwitchA-Vlan-interface100] ip address 2.1.1.1 24
[SwitchA-Vlan-interface100] quit
```
 - # Add Twenty-FiveGigE 1/0/1 to VLAN 101.


```
[SwitchA] vlan 101
[SwitchA-vlan101] port twenty-fivegige 1/0/1
[SwitchA-vlan101] quit
```
 - # Specify a 6to4 address for VLAN-interface 101.


```
[SwitchA] interface vlan-interface 101
[SwitchA-Vlan-interface101] ipv6 address 2002:0201:0101:1::1/64
[SwitchA-Vlan-interface101] quit
```
 - # Create service loopback group 1, and specify its service type as **tunnel**.


```
[SwitchA] service-loopback group 1 type tunnel
```
 - # Assign Twenty-FiveGigE 1/0/3 to service loopback group 1.


```
[SwitchA] interface twenty-fivegige 1/0/3
[SwitchA-Twenty-FiveGigE1/0/3] port service-loopback group 1
```

```

[SwitchA-Twenty-FiveGigE1/0/3] quit
# Create 6to4 tunnel interface Tunnel 0.
[SwitchA] interface tunnel 0 mode ipv6-ipv4 6to4
# Specify an IPv6 address for the tunnel interface.
[SwitchA-Tunnel0] ipv6 address 3001::1/64
# Specify the source interface as VLAN-interface 100 for the tunnel interface.
[SwitchA-Tunnel0] source vlan-interface 100
[SwitchA-Tunnel0] quit
# Configure a static route destined for 2002::/16 through the tunnel interface.
[SwitchA] ipv6 route-static 2002:: 16 tunnel 0

```

- **Configure Switch B:**

```

# Add Twenty-FiveGigE 1/0/2 (the physical interface of the tunnel) to VLAN 100.
<SwitchB> system-view
[SwitchB] vlan 100
[SwitchB-vlan100] port twenty-fivegige 1/0/2
[SwitchB-vlan100] quit
# Specify an IPv4 address for VLAN-interface 100.
[SwitchB] interface vlan-interface 100
[SwitchB-Vlan-interface100] ip address 5.1.1.1 24
[SwitchB-Vlan-interface100] quit
# Add Twenty-FiveGigE 1/0/1 to VLAN 101.
[SwitchB] vlan 101
[SwitchB-vlan101] port twenty-fivegige 1/0/1
[SwitchB-vlan101] quit
# Specify a 6to4 address for VLAN-interface 101.
[SwitchB] interface vlan-interface 101
[SwitchB-Vlan-interface101] ipv6 address 2002:0501:0101:1::1/64
[SwitchB-Vlan-interface101] quit
# Create service loopback group 1, and specify its service type as tunnel.
[SwitchB] service-loopback group 1 type tunnel
# Assign Twenty-FiveGigE 1/0/3 to service loopback group 1.
[SwitchB] interface twenty-fivegige 1/0/3
[SwitchB-Twenty-FiveGigE1/0/3] port service-loopback group 1
[SwitchB-Twenty-FiveGigE1/0/3] quit
# Create 6to4 tunnel interface Tunnel 0.
[SwitchB] interface tunnel 0 mode ipv6-ipv4 6to4
# Specify an IPv6 address for the tunnel interface.
[SwitchA-Tunnel0] ipv6 address 3002::1/64
# Specify the source interface as VLAN-interface 100 for the tunnel interface.
[SwitchB-Tunnel0] source vlan-interface 100
[SwitchB-Tunnel0] quit
# Configure a static route destined for 2002::/16 through the tunnel interface.
[SwitchB] ipv6 route-static 2002:: 16 tunnel 0

```

Verifying the configuration

```

# Verify that Host A and Host B can ping each other.
D:\>ping6 -s 2002:201:101:1::2 2002:501:101:1::2

```

```

Pinging 2002:501:101:1::2
from 2002:201:101:1::2 with 32 bytes of data:

Reply from 2002:501:101:1::2: bytes=32 time=13ms
Reply from 2002:501:101:1::2: bytes=32 time=1ms
Reply from 2002:501:101:1::2: bytes=32 time=1ms
Reply from 2002:501:101:1::2: bytes=32 time<1ms

Ping statistics for 2002:501:101:1::2:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
    Minimum = 0ms, Maximum = 13ms, Average = 3ms

```


Example: Configuring 6to4 relay

Network configuration

As shown in [Figure 6](#), Switch A is a 6to4 switch, and 6to4 addresses are used on the connected IPv6 network. Switch B acts as a 6to4 relay switch and is connected to the IPv6 network (2001::/16). Configure a 6to4 tunnel between Switch A and Switch B to make Host A and Host B reachable to each other.

The configuration on a 6to4 relay switch is similar to that on a 6to4 switch. To enable communication between the 6to4 network and the IPv6 network, configure a route destined for the IPv6 network on the 6to4 switch. The IPv4 address of VLAN-interface 100 on the relay switch is 6.1.1.1/24 and its corresponding 6to4 prefix is 2002:0601:0101::/48. The next hop of the static route must be an address using this prefix.

Figure 6 Network diagram



Procedure

Make sure Switch A and Switch B have the corresponding VLAN interfaces created and can reach each other through IPv4.

- Configure Switch A:


```

# Add Twenty-FiveGigE 1/0/2 (the physical interface of the tunnel) to VLAN 100.
<SwitchA> system-view
[SwitchA] vlan 100
[SwitchA-vlan100] port twenty-fivegige 1/0/2
[SwitchA-vlan100] quit

```

Specify an IPv4 address for VLAN-interface 100.

```
[SwitchA] interface vlan-interface 100
[SwitchA-Vlan-interface100] ip address 2.1.1.1 255.255.255.0
[SwitchA-Vlan-interface100] quit
```

Add Twenty-FiveGigE 1/0/1 to VLAN 101.

```
[SwitchA] vlan 101
[SwitchA-vlan101] port twenty-fivegige 1/0/1
[SwitchA-vlan101] quit
```

Specify a 6to4 address for VLAN-interface 101.

```
[SwitchA] interface vlan-interface 101
[SwitchA-Vlan-interface101] ipv6 address 2002:0201:0101:1::1/64
[SwitchA-Vlan-interface101] quit
```

Create service loopback group 1, and specify its service type as **tunnel.**

```
[SwitchA] service-loopback group 1 type tunnel
```

Assign Twenty-FiveGigE 1/0/3 to service loopback group 1.

```
[SwitchA] interface twenty-fivegige 1/0/3
[SwitchA-Twenty-FiveGigE1/0/3] port service-loopback group 1
[SwitchA-Twenty-FiveGigE1/0/3] quit
```

Create 6to4 tunnel interface Tunnel 0.

```
[SwitchA] interface tunnel 0 mode ipv6-ipv4 6to4
```

Specify an IPv6 address for the tunnel interface.

```
[SwitchA-Tunnel0] ipv6 address 2002::1/64
```

Specify the source interface as VLAN-interface 100 for the tunnel interface.

```
[SwitchA-Tunnel0] source vlan-interface 100
[SwitchA-Tunnel0] quit
```

Configure a static route destined for the 6to4 relay switch.

```
[SwitchA] ipv6 route-static 2002:0601:0101:: 64 tunnel 0
```

Configure a default route to reach the IPv6 network, which specifies the 6to4 address of the 6to4 relay switch as the next hop.

```
[SwitchA] ipv6 route-static :: 0 2002:0601:0101::1
```

- **Configure Switch B:**

Add Twenty-FiveGigE 1/0/2 (the physical interface of the tunnel) to VLAN 100.

```
<SwitchB> system-view
[SwitchB] vlan 100
[SwitchB-vlan100] port twenty-fivegige 1/0/2
[SwitchB-vlan100] quit
```

Specify an IPv4 address for VLAN-interface 100.

```
[SwitchB] interface vlan-interface 100
[SwitchB-Vlan-interface100] ip address 6.1.1.1 255.255.255.0
[SwitchB-Vlan-interface100] quit
```

Add Twenty-FiveGigE 1/0/1 to VLAN 101.

```
[SwitchB] vlan 101
[SwitchB-vlan101] port twenty-fivegige 1/0/1
[SwitchB-vlan101] quit
```

Specify an IPv6 address for VLAN-interface 101.

```
[SwitchB] interface vlan-interface 101
[SwitchB-Vlan-interface101] ipv6 address 2001::1/16
```

```

[SwitchB-Vlan-interface101] quit
# Create service loopback group 1, and specify its service type as tunnel.
[SwitchB] service-loopback group 1 type tunnel
# Assign Twenty-FiveGigE 1/0/3 to service loopback group 1.
[SwitchB] interface twenty-fivegige 1/0/3
[SwitchB-Twenty-FiveGigE1/0/3] port service-loopback group 1
[SwitchB-Twenty-FiveGigE1/0/3] quit
# Create 6to4 tunnel interface Tunnel 0.
[SwitchB] interface tunnel 0 mode ipv6-ipv4 6to4
# Specify an IPv6 address for the tunnel interface.
[SwitchB-Tunnel0] ipv6 address 2003::1/64
# Specify VLAN-interface 100 as the source interface of the tunnel interface.
[SwitchB-Tunnel0] source vlan-interface 100
[SwitchB-Tunnel0] quit
# Configure a static route destined for 2002::/16 through the tunnel interface.
[SwitchB] ipv6 route-static 2002:: 16 tunnel 0

```

Verifying the configuration

```
# Verify that Host A and Host B can ping each other.
```

```
D:\>ping6 -s 2002:201:101:1::2 2001::2
```

```
Pinging 2001::2
from 2002:201:101:1::2 with 32 bytes of data:
```

```
Reply from 2001::2: bytes=32 time=13ms
Reply from 2001::2: bytes=32 time=1ms
Reply from 2001::2: bytes=32 time=1ms
Reply from 2001::2: bytes=32 time<1ms
```

```
Ping statistics for 2001::2:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
    Minimum = 0ms, Maximum = 13ms, Average = 3ms
```

Configuring an ISATAP tunnel

Restrictions and guidelines

Follow these guidelines when you configure an ISATAP tunnel:

- You do not need to configure a destination address for an ISATAP tunnel, because the destination IPv4 address is embedded in the ISATAP address.
- Do not specify the same source addresses for local tunnel interfaces in the same tunnel mode.
- Automatic tunnels do not support dynamic routing. You must configure a static route destined for the destination IPv6 network if the destination IPv6 network is not in the same subnet as the IPv6 address of the tunnel interface. You can specify the local tunnel interface as the egress interface of the route or specify the IPv6 address of the peer tunnel interface as the next hop of the route. The route configuration is required on both ends of the tunnel. For more information about route configuration, see *Layer 3—IP Routing Configuration Guide*.

Procedure


1. Enter system view.
system-view
2. Enter ISATAP tunnel interface view.
interface tunnel number [mode ipv6-ipv4 isatap]
3. Specify an IPv6 address for the tunnel interface.
See "Configuring basic IPv6 settings."
4. Configure a source address or source interface for the tunnel interface.
source { ipv4-address | interface-type interface-number }
By default, no source address or source interface is configured for the tunnel interface.
If you specify a source address, it is used as the source IP address of tunneled packets.
If you specify a source interface, the primary IP address of this interface is used as the source IP address of tunneled packets.
5. (Optional.) Set the DF bit for tunneled packets.
tunnel dfbit enable
By default, the DF bit is not set for tunneled packets.

Example: Configuring an ISATAP tunnel

Network configuration

As shown in [Figure 7](#), configure an ISATAP tunnel between the switch and the ISATAP host so the ISATAP host in the IPv4 network can access the IPv6 network.

Figure 7 Network diagram



Procedure

- Configure the switch:
Add Twenty-FiveGigE 1/0/1 to VLAN 100.

```
<Switch> system-view  
[Switch] vlan 100  
[Switch-vlan100] port twenty-fivegige 1/0/1  
[Switch-vlan100] quit
```


Specify an IPv6 address for VLAN-interface 100.

```
[Switch] interface vlan-interface 100  
[Switch-Vlan-interface100] ipv6 address 3001::1/64  
[Switch-Vlan-interface100] quit
```


Add Twenty-FiveGigE 1/0/2 (the physical interface of the tunnel) to VLAN 101.

```
[Switch] vlan 101  
[Switch-vlan101] port twenty-fivegige 1/0/2
```

```

[Switch-vlan101] quit
# Specify an IPv4 address for VLAN-interface 101.
[Switch] interface vlan-interface 101
[Switch-Vlan-interface101] ip address 1.1.1.1 255.0.0.0
[Switch-Vlan-interface101] quit
# Create service loopback group 1, and specify its service type as tunnel.
[Switch] service-loopback group 1 type tunnel
# Assign Twenty-FiveGigE 1/0/3 to service loopback group 1.
[Switch] interface twenty-fivegige 1/0/3
[Switch-Twenty-FiveGigE1/0/3] port service-loopback group 1
[Switch-Twenty-FiveGigE1/0/3] quit
# Create ISATAP tunnel interface Tunnel 0.
[Switch] interface tunnel 0 mode ipv6-ipv4 isatap
# Specify an EUI-64 IPv6 address for the tunnel interface.
[Switch-Tunnel0] ipv6 address 2001:: 64 eui-64
# Specify VLAN-interface 101 as the source interface of the tunnel interface.
[Switch-Tunnel0] source vlan-interface 101
# Disable RA suppression so that the ISATAP host can acquire information such as the address
prefix from the RA message advertised by the ISATAP switch.
[Switch-Tunnel0] undo ipv6 nd ra halt
[Switch-Tunnel0] quit

```

- **Configure the ISATAP host:**

Configurations on the ISATAP host vary by operating system. The following configuration is performed on Windows XP.

Install IPv6.

```
C:\>ipv6 install
```

On a host running Windows XP, the ISATAP interface is typically interface 2. Display information about the ISATAP interface.

```

C:\>ipv6 if 2
Interface 2: Automatic Tunneling Pseudo-Interface
    Guid {48FCE3FC-EC30-E50E-F1A7-71172AEEE3AE}
    does not use Neighbor Discovery
    does not use Router Discovery
    routing preference 1
    EUI-64 embedded IPv4 address: 0.0.0.0
    router link-layer address: 0.0.0.0
    preferred link-local fe80::5efe:1.1.1.2, life infinite
    link MTU 1280 (true link MTU 65515)
    current hop limit 128
    reachable time 42500ms (base 30000ms)
    retransmission interval 1000ms
    DAD transmits 0
    default site prefix length 48

```

Specify an IPv4 address for the ISATAP switch.

```
C:\>netsh interface ipv6 isatap set router 1.1.1.1
```

Display information about the ISATAP interface.

```

C:\>ipv6 if 2
Interface 2: Automatic Tunneling Pseudo-Interface

```

```

Guid {48FCE3FC-EC30-E50E-F1A7-71172AEEE3AE}
does not use Neighbor Discovery
uses Router Discovery
routing preference 1
EUI-64 embedded IPv4 address: 1.1.1.2
router link-layer address: 1.1.1.1
    preferred global 2001::5efe:1.1.1.2, life 29d23h59m46s/6d23h59m46s (public)
    preferred link-local fe80::5efe:1.1.1.2, life infinite
link MTU 1500 (true link MTU 65515)
current hop limit 255
reachable time 42500ms (base 30000ms)
retransmission interval 1000ms
DAD transmits 0
default site prefix length 48

```

The host has obtained the address prefix 2001::/64 and has automatically generated the global unicast address 2001::5efe:1.1.1.2. The message "uses Router Discovery" indicates that the router discovery feature is enabled on the host.

Display information about IPv6 routes on the host.

```

C:\>ipv6 rt
2001::/64 -> 2 pref lif+8=9 life 29d23h59m43s (autoconf)
::/0 -> 2/fe80::5efe:1.1.1.1 pref lif+256=257 life 29m43s (autoconf)

```

- On the IPv6 host, configure a route to the ISATAP switch.

```

C:\>netsh interface ipv6 set route 2001::/64 5 3001::1

```

Verifying the configuration

Verify that the ISATAP host can ping the IPv6 host.

```

C:\>ping 3001::2

```

```

Pinging 3001::2 with 32 bytes of data:

```

```

Reply from 3001::2: time=1ms
Reply from 3001::2: time=1ms
Reply from 3001::2: time=1ms
Reply from 3001::2: time=1ms

```

```

Ping statistics for 3001::2:

```

```

    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
    Minimum = 1ms, Maximum = 1ms, Average = 1ms

```

Enabling dropping IPv6 packets that use IPv4-compatible IPv6 addresses

1. Enter system view.
system-view
2. Enable dropping IPv6 packets that use IPv4-compatible IPv6 addresses.
tunnel discard ipv4-compatible-packet

By default, IPv6 packets that use IPv4-compatible IPv6 addresses are not dropped.

IPv4 over IPv4 tunneling

About IPv4 over IPv4 tunneling

IPv4 over IPv4 tunneling (RFC 1853) enables isolated IPv4 networks to communicate. For example, an IPv4 over IPv4 tunnel can connect isolated private IPv4 networks over a public IPv4 network.

Figure 8 IPv4 over IPv4 tunnel




Figure 8 shows the encapsulation and de-encapsulation processes.

- Encapsulation:
 - a. Device A receives an IP packet from an IPv4 host and submits it to the IP protocol stack.
 - b. The IPv4 protocol stack determines how to forward the packet according to the destination address in the IP header. If the packet is destined for the IPv4 host connected to Device B, Device A delivers the packet to the tunnel interface.
 - c. The tunnel interface adds a new IPv4 header to the IPv4 packet and submits it to the IP protocol stack.

In the new header, the source IP address specifies the tunnel source, and the destination IP address specifies the tunnel destination.
 - d. The IP protocol stack uses the destination IP address of the new IP header to look up the routing table, and then sends the packet out.
- De-encapsulation:
 - e. After receiving the packet, Device B delivers it to the IP protocol stack.
 - f. If the protocol number is 4 (indicating an IPv4 packet is encapsulated within the packet), the IP protocol stack delivers the packet to the tunnel module for de-encapsulation.
 - g. The tunnel module de-encapsulates the IP packet and sends it back to the IP protocol stack.
 - h. The protocol stack forwards the de-encapsulated packet.

Restrictions and guidelines: IPv4 over IPv4 tunnel configuration

Follow these guidelines when you configure an IPv4 over IPv4 tunnel:

- The tunnel destination address specified on the local device must be identical with the tunnel source address specified on the tunnel peer device.

- Do not specify the same source and destination addresses for local tunnel interfaces in the same tunnel mode.
- The IPv4 address of the local tunnel interface cannot be on the same subnet as the destination address configured on the tunnel interface.
- To ensure correct packet forwarding, identify whether the destination IPv4 network and the IPv4 address of the local tunnel interface are on the same subnet. If they are not, configure a route reaching the destination IPv4 network through the tunnel interface. You can configure the route by using one of the following methods:
 - Configure a static route, and specify the local tunnel interface as the egress interface or specify the IPv4 address of the peer tunnel interface as the next hop.
 - Enable a dynamic routing protocol on the tunnel interface.

The route configuration is required on both ends of the tunnel. For more information about route configuration, see *Layer 3—IP Routing Configuration Guide*.

- The destination address of the route passing the tunnel interface cannot be on the same subnet as the destination address configured on the tunnel interface.

Configuring an IPv4 over IPv4 tunnel

1. Enter system view.

```
system-view
```

2. Enter IPv4 over IPv4 tunnel interface view.

```
interface tunnel number [ mode ipv4-ipv4 ]
```

3. Configure an IPv4 address for the tunnel interface.

```
ip address ip-address { mask | mask-length } [ sub ]
```

4. Configure a source address or source interface for the tunnel interface.

```
source { ipv4-address | interface-type interface-number }
```

By default, no source address or source interface is configured for the tunnel interface.

If you specify a source address, it is used as the source IP address of tunneled packets.

If you specify a source interface, the primary IP address of this interface is used as the source IP address of tunneled packets.

5. Configure a destination address for the tunnel interface.

```
destination ipv4-address
```

By default, no destination address is configured for the tunnel interface.

The tunnel destination address must be the IP address of the receiving interface on the tunnel peer. It is used as the destination IP address of tunneled packets.

6. (Optional.) Set the DF bit for tunneled packets.

```
tunnel dfbit enable
```

By default, the DF bit is not set for tunneled packets.


IPv4 over IPv4 tunnel configuration examples

Example: Configuring an IPv4 over IPv4 tunnel

Network configuration

As shown in [Figure 9](#), the two subnets IPv4 group 1 and IPv4 group 2 use private IPv4 addresses. Configure an IPv4 over IPv4 tunnel between Switch A and Switch B to make the two subnets reachable to each other.

Figure 9 Network diagram



Procedure

Make sure Switch A and Switch B have the corresponding VLAN interfaces created and can reach each other through IPv4.

- Configure Switch A:

Add Twenty-FiveGigE 1/0/1 to VLAN 100.

```
<SwitchA> system-view
[SwitchA] vlan 100
[SwitchA-vlan100] port twenty-fivegige 1/0/1
[SwitchA-vlan100] quit
```

Specify an IPv4 address for VLAN-interface 100.

```
[SwitchA] interface vlan-interface 100
[SwitchA-Vlan-interface100] ip address 10.1.1.1 255.255.255.0
[SwitchA-Vlan-interface100] quit
```

Add Twenty-FiveGigE 1/0/2 (the physical interface of the tunnel) to VLAN 101.

```
[SwitchA] vlan 101
[SwitchA-vlan101] port twenty-fivegige 1/0/2
[SwitchA-vlan101] quit
```

Specify an IPv4 address for VLAN-interface 101.

```
[SwitchA] interface vlan-interface 101
[SwitchA-Vlan-interface101] ip address 2.1.1.1 255.255.255.0
[SwitchA-Vlan-interface101] quit
```

Create service loopback group 1, and specify its service type as **tunnel**.

```
[SwitchA] service-loopback group 1 type tunnel
```

Assign Twenty-FiveGigE 1/0/3 to service loopback group 1.

```
[SwitchA] interface twenty-fivegige 1/0/3
[SwitchA-Twenty-FiveGigE1/0/3] port service-loopback group 1
[SwitchA-Twenty-FiveGigE1/0/3] quit
```

Create IPv4 over IPv4 tunnel interface Tunnel 1.

```
[SwitchA] interface tunnel 1 mode ipv4-ipv4
# Specify an IPv4 address for the tunnel interface.
[SwitchA-Tunnel1] ip address 10.1.2.1 255.255.255.0
# Specify the IP address of VLAN-interface 101 as the source address for the tunnel interface.
[SwitchA-Tunnel1] source 2.1.1.1
# Specify the IP address of VLAN-interface 101 on Switch B as the destination address for the
tunnel interface.
[SwitchA-Tunnel1] destination 3.1.1.1
[SwitchA-Tunnel1] quit
# Configure a static route destined for IPv4 group 2 through the tunnel interface.
[SwitchA] ip route-static 10.1.3.0 255.255.255.0 tunnel 1
```

- **Configure Switch B:**

```
# Add Twenty-FiveGigE 1/0/1 to VLAN 100.
<SwitchB> system-view
[SwitchB] vlan 100
[SwitchB-vlan100] port twenty-fivegige 1/0/1
[SwitchB-vlan100] quit
# Specify an IPv4 address for VLAN-interface 100.
[SwitchB] interface vlan-interface 100
[SwitchB-Vlan-interface100] ip address 10.1.3.1 255.255.255.0
[SwitchB-Vlan-interface100] quit
# Add Twenty-FiveGigE 1/0/2 (the physical interface of the tunnel) to VLAN 101.
[SwitchB] vlan 101
[SwitchB-vlan101] port twenty-fivegige 1/0/2
[SwitchB-vlan101] quit
# Specify an IPv4 address for VLAN-interface 101.
[SwitchB] interface vlan-interface 101
[SwitchB-Vlan-interface101] ip address 3.1.1.1 255.255.255.0
[SwitchB-Vlan-interface101] quit
# Create service loopback group 1, and specify its service type as tunnel.
[SwitchB] service-loopback group 1 type tunnel
# Assign Twenty-FiveGigE 1/0/3 to service loopback group 1.
[SwitchB] interface twenty-fivegige 1/0/3
[SwitchB-Twenty-FiveGigE1/0/3] port service-loopback group 1
[SwitchB-Twenty-FiveGigE1/0/3] quit
# Create IPv4 over IPv4 tunnel interface Tunnel 2.
[SwitchB] interface tunnel 2 mode ipv4-ipv4
# Specify an IPv4 address for the tunnel interface.
[SwitchB-Tunnel2] ip address 10.1.2.2 255.255.255.0
# Specify the IP address of VLAN-interface 101 as the source address for the tunnel interface.
[SwitchB-Tunnel2] source 3.1.1.1
# Specify the IP address of VLAN-interface 101 on Switch A as the destination address for the
tunnel interface.
[SwitchB-Tunnel2] destination 2.1.1.1
[SwitchB-Tunnel2] quit
# Configure a static route destined for IPv4 group 1 through the tunnel interface.
[SwitchB] ip route-static 10.1.1.0 255.255.255.0 tunnel 2
```

Verifying the configuration

Use the **display interface tunnel** command to display the status of the tunnel interfaces on Switch A and Switch B. Verify that the tunnel interfaces are up. (Details not shown.)

Verify that Switch A and Switch B can ping the IPv4 address of the peer interface VLAN-interface 100. This example uses Switch A.

```
[SwitchA] ping -a 10.1.1.1 10.1.3.1
Ping 10.1.3.1 (10.1.3.1) from 10.1.1.1: 56 data bytes, press CTRL_C to break
56 bytes from 10.1.3.1: icmp_seq=0 ttl=255 time=2.000 ms
56 bytes from 10.1.3.1: icmp_seq=1 ttl=255 time=1.000 ms
56 bytes from 10.1.3.1: icmp_seq=2 ttl=255 time=0.000 ms
56 bytes from 10.1.3.1: icmp_seq=3 ttl=255 time=1.000 ms
56 bytes from 10.1.3.1: icmp_seq=4 ttl=255 time=1.000 ms

--- Ping statistics for 10.1.3.1 ---
5 packet(s) transmitted, 5 packet(s) received, 0.0% packet loss
round-trip min/avg/max/std-dev = 0.000/1.000/2.000/0.632 ms
```

IPv4 over IPv6 tunneling

About IPv4 over IPv6 tunneling

IPv4 over IPv6 tunneling adds an IPv6 header to IPv4 packets so that the IPv4 packets can pass an IPv6 network through a tunnel to realize interworking between isolated IPv4 networks.

Figure 10 IPv4 over IPv6 tunnel




Figure 10 shows the encapsulation and de-encapsulation processes.

- Encapsulation:
 - a. Upon receiving an IPv4 packet, Device A delivers it to the IPv4 protocol stack.
 - b. The IPv4 protocol stack uses the destination address of the packet to determine the egress interface. If the egress interface is the tunnel interface, the IPv4 protocol stack delivers the packet to the tunnel interface.
 - c. The tunnel interface adds an IPv6 header to the original IPv4 packet and delivers the packet to the IPv6 protocol stack.
 - d. The IPv6 protocol stack uses the destination IPv6 address of the packet to look up the routing table, and then sends it out.
- De-encapsulation:
 - e. Upon receiving the IPv6 packet from the attached IPv6 network, Device B delivers the packet to the IPv6 protocol stack to examine the protocol type encapsulated in the data portion of the packet.
 - f. If the protocol type is IPv4, the IPv6 protocol stack delivers the packet to the tunneling module.
 - g. The tunneling module removes the IPv6 header and delivers the remaining IPv4 packet to the IPv4 protocol stack.
 - h. The IPv4 protocol stack forwards the IPv4 packet.

Configuring an IPv4 over IPv6 tunnel

Restrictions and guidelines

When you perform the tasks in this section, follow these restrictions and guidelines:

- The tunnel destination address specified on the local device must be identical with the tunnel source address specified on the tunnel peer device.

- Do not specify the same source and destination addresses for local tunnel interfaces in the same tunnel mode.
- To ensure correct packet forwarding, identify whether the destination IPv4 network and the IPv4 address of the local tunnel interface are on the same subnet. If they are not, configure a static route reaching the destination IPv4 network through the tunnel interface. You can specify the local tunnel interface as the egress interface or specify the IPv6 address of the peer tunnel interface as the next hop in the static route. The route configuration is required on both ends of the tunnel.

For more information about static route configuration, see *Layer 3—IP Routing Configuration Guide*.

Procedure


1. Enter system view.
system-view
 2. Enter IPv6 tunnel interface view.
interface tunnel *number* [**mode ipv6**]
 3. Configure an IPv4 address for the tunnel interface.
ip address *ip-address* { *mask* | *mask-length* } [**sub**]
 4. Configure the source address or interface for the tunnel interface.
source { *ipv6-address* | *interface-type interface-number* }
- By default, no source address or interface is configured for the tunnel.
If you specify a source address, it is used as the source IPv6 address of tunneled packets.
If you specify a source interface, the lowest IPv6 address of this interface is used as the source IPv6 address of tunneled packets.
5. Configure the destination address for the tunnel interface.
destination *ipv6-address*
- By default, no destination address is configured for the tunnel.
The tunnel destination address must be the IPv6 address of the receiving interface on the tunnel peer. It is used as the destination IPv6 address of tunneled packets.

Example: Configuring an IPv4 over IPv6 tunnel

Network configuration

As shown in [Figure 11](#), configure an IPv4 over IPv6 tunnel between Switch A and Switch B so the two networks can reach each other over the IPv6 network.

Figure 11 Network diagram



Procedure

Make sure Switch A and Switch B have the corresponding VLAN interfaces created and can reach each other through IPv6.

- **Configure Switch A:**

Add Twenty-FiveGigE 1/0/1 to VLAN 100.

```
<SwitchA> system-view
[SwitchA] vlan 100
[SwitchA-vlan100] port twenty-fivegige 1/0/1
[SwitchA-vlan100] quit
```

Specify an IPv4 address for VLAN-interface 100.

```
[SwitchA] interface vlan-interface 100
[SwitchA-Vlan-interface100] ip address 30.1.1.1 255.255.255.0
[SwitchA-Vlan-interface100] quit
```

Add Twenty-FiveGigE 1/0/2 (the physical interface of the tunnel) to VLAN 101.

```
[SwitchA] vlan 101
[SwitchA-vlan101] port twenty-fivegige 1/0/2
[SwitchA-vlan101] quit
```

Specify an IPv6 address for VLAN-interface 101.

```
[SwitchA] interface vlan-interface 101
[SwitchA-Vlan-interface101] ipv6 address 2001::1:1 64
[SwitchA-Vlan-interface101] quit
```

Create service loopback group 1, and specify its service type as **tunnel.**

```
[SwitchA] service-loopback group 1 type tunnel
```

Assign Twenty-FiveGigE 1/0/3 to service loopback group 1.

```
[SwitchA] interface twenty-fivegige 1/0/3
[SwitchA-Twenty-FiveGigE1/0/3] port service-loopback group 1
[SwitchA-Twenty-FiveGigE1/0/3] quit
```

Create IPv6 tunnel interface Tunnel 1.

```
[SwitchA] interface tunnel 1 mode ipv6
```

Specify an IPv4 address for the tunnel interface.

```
[SwitchA-Tunnel1] ip address 30.1.2.1 255.255.255.0
```

Specify the IP address of VLAN-interface 101 as the source address for the tunnel interface.

```
[SwitchA-Tunnel1] source 2001::1:1
```

Specify the IP address of VLAN-interface 101 on Switch B as the destination address for the tunnel interface.

```
[SwitchA-Tunnel1] destination 2002::2:1
```

```
[SwitchA-Tunnel1] quit
```

Configure a static route destined for IPv4 network 2 through the tunnel interface.

```
[SwitchA] ip route-static 30.1.3.0 255.255.255.0 tunnel 1
```

- **Configure Switch B:**

Add Twenty-FiveGigE 1/0/1 to VLAN 100.

```
<SwitchB> system-view
[SwitchB] vlan 100
[SwitchB-vlan100] port twenty-fivegige 1/0/1
[SwitchB-vlan100] quit
```

Specify an IPv4 address for VLAN-interface 100.

```
[SwitchB] interface vlan-interface 100
```

```

[SwitchB-Vlan-interface100] ip address 30.1.3.1 255.255.255.0
[SwitchB-Vlan-interface100] quit
# Add Twenty-FiveGigE 1/0/2 (the physical interface of the tunnel) to VLAN 101.
[SwitchB] vlan 101
[SwitchB-vlan101] port twenty-fivegige 1/0/2
[SwitchB-vlan101] quit
# Specify an IPv6 address for VLAN-interface 101.
[SwitchB] interface vlan-interface 101
[SwitchB-Vlan-interface101] ipv6 address 2002::2:1 64
[SwitchB-Vlan-interface101] quit
# Create service loopback group 1, and specify its service type as tunnel.
[SwitchB] service-loopback group 1 type tunnel
# Assign Twenty-FiveGigE 1/0/3 to service loopback group 1.
[SwitchB] interface twenty-fivegige 1/0/3
[SwitchB-Twenty-FiveGigE1/0/3] port service-loopback group 1
[SwitchB-Twenty-FiveGigE1/0/3] quit
# Create IPv6 tunnel interface Tunnel 2.
[SwitchB] interface tunnel 2 mode ipv6
# Specify an IPv4 address for the tunnel interface.
[SwitchB-Tunnel2] ip address 30.1.2.2 255.255.255.0
# Specify the IP address of VLAN-interface 101 as the source address for the tunnel interface
(IP address of VLAN-interface 101).
[SwitchB-Tunnel2] source 2002::2:1
# Specify the IP address of VLAN-interface 101 on Switch A as the destination address for the
tunnel interface.
[SwitchB-Tunnel2] destination 2001::1:1
[SwitchB-Tunnel2] quit
# Configure a static route destined for IPv4 network 1 through the tunnel interface.
[SwitchB] ip route-static 30.1.1.0 255.255.255.0 tunnel 2

```

Verifying the configuration

Use the **display interface tunnel** command to display the status of the tunnel interfaces on Switch A and Switch B. Verify that the tunnel interfaces are up. (Details not shown.)

Verify that Switch A and Switch B can ping the IPv4 address of the peer interface. This example uses Switch A.

```

[SwitchA] ping -a 30.1.1.1 30.1.3.1
Ping 30.1.3.1 (30.1.3.1) from 30.1.1.1: 56 data bytes, press CTRL_C to break
56 bytes from 30.1.3.1: icmp_seq=0 ttl=255 time=3.000 ms
56 bytes from 30.1.3.1: icmp_seq=1 ttl=255 time=1.000 ms
56 bytes from 30.1.3.1: icmp_seq=2 ttl=255 time=0.000 ms
56 bytes from 30.1.3.1: icmp_seq=3 ttl=255 time=1.000 ms
56 bytes from 30.1.3.1: icmp_seq=4 ttl=255 time=1.000 ms

--- Ping statistics for 30.1.3.1 ---
5 packet(s) transmitted, 5 packet(s) received, 0.0% packet loss
round-trip min/avg/max/std-dev = 0.000/1.200/3.000/0.980 ms

```

IPv6 over IPv6 tunneling

About IPv6 over IPv6 tunneling

IPv6 over IPv6 tunneling (RFC 2473) enables isolated IPv6 networks to communicate with each other over another IPv6 network. For example, two isolated IPv6 networks that do not want to show their addresses to the Internet can use an IPv6 over IPv6 tunnel to communicate with each other.

Figure 12 Principle of IPv6 over IPv6 tunneling




Figure 12 shows the encapsulation and de-encapsulation processes.

- Encapsulation:
 - a. After receiving an IPv6 packet, Device A submits it to the IPv6 protocol stack.
 - b. The IPv6 protocol stack uses the destination IPv6 address of the packet to find the egress interface. If the egress interface is the tunnel interface, the stack delivers it to the tunnel interface.
 - c. After receiving the packet, the tunnel interface adds an IPv6 header to it and submits it to the IPv6 protocol stack.
 - d. The IPv6 protocol stack forwards the packet according to its destination IPv6 address.
- De-encapsulation:
 - e. Upon receiving the IPv6 packet, Device B delivers it to the IPv6 protocol stack.
 - f. The IPv6 protocol stack checks the protocol type of the data portion encapsulated in the IPv6 packet. If the encapsulation protocol is IPv6, the stack delivers the packet to the tunnel module.
 - g. The tunnel module de-encapsulates the packet and sends it back to the IPv6 protocol stack.
 - h. The IPv6 protocol stack forwards the IPv6 packet.

Restrictions and guidelines: IPv6 over IPv6 tunnel configuration

Follow these guidelines when you configure an IPv6 over IPv6 tunnel:

- The tunnel destination address specified on the local device must be identical with the tunnel source address specified on the tunnel peer device.
- Do not specify the same source and destination addresses for local tunnel interfaces in the same tunnel mode.

- The IPv6 address of the tunnel interface cannot be on the same subnet as the destination address configured for the tunnel interface.
- To ensure correct packet forwarding, identify whether the destination IPv6 network and the IPv6 address of the local tunnel interface are on the same subnet. If they are not, configure a static route reaching the destination IPv6 network through the tunnel interface. You can specify the local tunnel interface as the egress interface or specify the IPv6 address of the peer tunnel interface as the next hop in the static route. The route configuration is required on both ends of the tunnel.
For more information about IPv6 static route configuration, see *Layer 3—IP Routing Configuration Guide*.
- The destination address of the route passing the tunnel interface cannot be on the same subnet as the destination address configured for the tunnel interface.

IPv6 over IPv6 tunnel configuration tasks at a glance

To configure an IPv6 over IPv6 tunnel, perform the following tasks:

1. [Configuring an IPv6 over IPv6 tunnel](#)
2. (Optional.) [Enabling dropping IPv6 packets that use IPv4-compatible IPv6 addresses](#)

Configuring an IPv6 over IPv6 tunnel

1. Enter system view.
system-view
2. Enter IPv6 tunnel interface view.
interface tunnel *number* [**mode ipv6**]
3. Configure an IPv6 address for the tunnel interface.
See "Configuring basic IPv6 settings."
4. Configure the source address or source interface for the tunnel interface.
source { *ipv6-address* | *interface-type interface-number* }
By default, no source address or interface is configured for the tunnel.
If you specify a source address, it is used as the source IPv6 address of tunneled packets.
If you specify a source interface, the lowest IPv6 address of this interface is used as the source IPv6 address of tunneled packets.
5. Configure the destination address for the tunnel interface.
destination *ipv6-address*
By default, no destination address is configured for the tunnel.
The tunnel destination address must be the IPv6 address of the receiving interface on the tunnel peer. It is used as the destination IPv6 address of tunneled packets.

Enabling dropping IPv6 packets that use IPv4-compatible IPv6 addresses

1. Enter system view.
system-view

2. Enable dropping IPv6 packets that use IPv4-compatible IPv6 addresses.

```
tunnel discard ipv4-compatible-packet
```

By default, IPv6 packets that use IPv4-compatible IPv6 addresses are not dropped.


IPv6 over IPv6 tunnel configuration examples

Example: Configuring an IPv6 over IPv6 tunnel

Network configuration

As shown in [Figure 13](#), configure an IPv6 over IPv6 tunnel between Switch A and Switch B so the two networks can reach each other without disclosing their IPv6 addresses.

Figure 13 Network diagram



Procedure

Make sure Switch A and Switch B have the corresponding VLAN interfaces created and can reach each other through IPv6.

- Configure Switch A:

```
# Add Twenty-FiveGigE 1/0/1 to VLAN 100.
```

```
<SwitchA> system-view
[SwitchA] vlan 100
[SwitchA-vlan100] port twenty-fivegige 1/0/1
[SwitchA-vlan100] quit
```

```
# Specify an IPv6 address for VLAN-interface 100.
```

```
[SwitchA] interface vlan-interface 100
[SwitchA-Vlan-interface100] ipv6 address 2002:1::1 64
[SwitchA-Vlan-interface100] quit
```

```
# Add Twenty-FiveGigE 1/0/2 (the physical interface of the tunnel) to VLAN 101.
```

```
[SwitchA] vlan 101
[SwitchA-vlan101] port twenty-fivegige 1/0/2
[SwitchA-vlan101] quit
```

```
# Specify an IPv6 address for VLAN-interface 101.
```

```
[SwitchA] interface vlan-interface 101
[SwitchA-Vlan-interface101] ipv6 address 2001::11:1 64
[SwitchA-Vlan-interface101] quit
```

```
# Create service loopback group 1, and specify its service type as tunnel.
```

```
[SwitchA] service-loopback group 1 type tunnel
```

```
# Assign Twenty-FiveGigE 1/0/3 to service loopback group 1.
```

```
[SwitchA] interface twenty-fivegige 1/0/3
```

```

[SwitchA-Twenty-FiveGigE1/0/3] port service-loopback group 1
[SwitchA-Twenty-FiveGigE1/0/3] quit
# Create IPv6 tunnel interface Tunnel 1.
[SwitchA] interface tunnel 1 mode ipv6
# Specify an IPv6 address for the tunnel interface.
[SwitchA-Tunnel1] ipv6 address 3001::1:1 64
# Specify the IP address of VLAN-interface 101 as the source address for the tunnel interface.
[SwitchA-Tunnel1] source 2001::11:1
# Specify the IP address of VLAN-interface 101 on Switch B as the destination address for the tunnel interface.
[SwitchA-Tunnel1] destination 2002::22:1
[SwitchA-Tunnel1] quit
# Configure a static route destined for the IPv6 network group 2 through the tunnel interface.
[SwitchA] ipv6 route-static 2002:3:: 64 tunnel 1

```

- **Configure Switch B:**

```

# Add Twenty-FiveGigE 1/0/1 to VLAN 100.
<SwitchB> system-view
[SwitchB] vlan 100
[SwitchB-vlan100] port twenty-fivegige 1/0/1
[SwitchB-vlan100] quit
# Specify an IPv6 address for VLAN-interface 100.
[SwitchB] interface vlan-interface 100
[SwitchB-Vlan-interface100] ipv6 address 2002:3::1 64
[SwitchB-Vlan-interface100] quit
# Add Twenty-FiveGigE 1/0/2 (the physical interface of the tunnel) to VLAN 101.
[SwitchB] vlan 101
[SwitchB-vlan101] port twenty-fivegige 1/0/2
[SwitchB-vlan101] quit
# Specify an IPv6 address for VLAN-interface 101.
[SwitchB] interface vlan-interface 101
[SwitchB-Vlan-interface101] ipv6 address 2002::22:1 64
[SwitchB-Vlan-interface101] quit
# Create service loopback group 1, and specify its service type as tunnel.
[SwitchB] service-loopback group 1 type tunnel
# Assign Twenty-FiveGigE 1/0/3 to service loopback group 1.
[SwitchB] interface twenty-fivegige 1/0/3
[SwitchB-Twenty-FiveGigE1/0/3] port service-loopback group 1
[SwitchB-Twenty-FiveGigE1/0/3] quit
# Create IPv6 tunnel interface Tunnel 2.
[SwitchB] interface tunnel 2 mode ipv6
# Specify an IPv6 address for the tunnel interface.
[SwitchB-Tunnel2] ipv6 address 3001::1:2 64
# Specify the IP address of VLAN-interface 101 as the source address for the tunnel interface.
[SwitchB-Tunnel2] source 2002::22:1
# Specify the IP address of VLAN-interface 101 on Switch A as the destination address for the tunnel interface.
[SwitchB-Tunnel2] destination 2001::11:1

```

```
[SwitchB-Tunnel2] quit
# Configure a static route destined for the IPv6 network group 1 through the tunnel interface.
[SwitchB] ipv6 route-static 2002:1:: 64 tunnel 2
```

Verifying the configuration

Use the **display ipv6 interface** command to display the status of the tunnel interfaces on Switch A and Switch B. Verify that the tunnel interfaces are up. (Details not shown.)

Verify that Switch A and Switch B can ping the IPv4 address of the peer interface. This example uses Switch A.

```
[SwitchA] ping ipv6 -a 2002:1::1 2002:3::1
Ping6(56 data bytes) 2002:1::1 --> 2002:3::1, press CTRL_C to break
56 bytes from 2002:3::1, icmp_seq=0 hlim=64 time=9.000 ms
56 bytes from 2002:3::1, icmp_seq=1 hlim=64 time=1.000 ms
56 bytes from 2002:3::1, icmp_seq=2 hlim=64 time=0.000 ms
56 bytes from 2002:3::1, icmp_seq=3 hlim=64 time=0.000 ms
56 bytes from 2002:3::1, icmp_seq=4 hlim=64 time=0.000 ms

--- Ping6 statistics for 2002:3::1 ---
5 packet(s) transmitted, 5 packet(s) received, 0.0% packet loss
round-trip min/avg/max/std-dev = 0.000/2.000/9.000/3.521 ms
```